Heating, Ventilation and Air Conditioning

GENERAL

AIR CONDITIONING SYSTEM

COMPRESSOR OIL

A/C COMPRESSOR CONTROLS (MANUAL)

AIR CONDITIONING COMPRESSOR CONDENSER A/C PRESSURE TRANSDUCER REFRIGERANT LINE

HEATER

EVAPORATOR TEMPERATURE SENSOR HEATER UNIT PTC (POSITIVE TEMPERATURE COEFFICIENT) HEATER TEMPERATURE CONTROL ACTUATOR MODE CONTROL ACTUATOR

A/C COMPRESSOR CONTROLS (FULL AUTO)

IN CAR SENSOR PHOTO SENSOR WATER TEMPERATURE SENSOR AMBIENT TEMPERATURE SENSOR A.Q.S (AIR QUALITY SENSOR) HUMIDITY SENSOR

BLOWER CONTROLS

BLOWER UNIT BLOWER MOTOR BLOWER RELAY POWER MOSFET BLOWER RESISTOR A/C AIR FILTER INTAKE ACTUATOR

BLOWER AND A/C CONTROLS (MANUAL) CONTROL PANEL

BLOWER AND A/C CONTROLS (AUTO-MATIC) CONTROL PANEL



GENERAL

GENERAL

SPECIFICATION E56BFBD4

AIR CONDITIONER

Item		Specification			
		μ 2.7	λ 3.3	λ 3.8	D 2.2
	Туре	VS			
Compressor	Oil type & Capacity	FD 46XG (PAG), 150 ± 10cc			
Compressor	Pulley type	6PK-TYPE			
	Displacement	180cc/rev			
Condenser	Heat rejection	13,800 ± 5% kcal/hr			
(A/C pressure transducer) The method to measure pressure		Voltage = 0.00878835 * Pressure + 0.5[kgf/cm²]			essure
Expansion valve Type Block		ock			
Pofrigorant	Туре	R-134a			
Reingelant	Capacity [oz.(g)]	500 ± 25			

BLOWER UNIT

Item		Specification
Fresh and recirculation	Operating method	Actuator
Blower	Туре	Sirocco
	Speed step	Auto + 8 speed (Automatic), 4 speed (Manual)
	Speed control	Power mosfet (Automatic), Blower resistor (Manual)
Air filter	Туре	Particle filter

HEATER AND EVAPORATOR UNIT

lte	em	Specification
Heater	Туре	Pin & Tube type
	Heating capacity	4,600 ± 5% kcal/hr
	PTC heater capacity	1000W + 5%/-10%
	Mode operating method	Actuator
	Temperature operating method	Actuator
	Temperature control type	Evaporator temperature sensor
Evaporator	A/C ON/OFF [℃(°F)]	ON : 2.1 ± 0.5 (35.8 ± 32.9), OFF: 0.6 ± 0.5 (33.1 ± 32.9)

TROUBLESHOOTING EDABEDD2

PROBLEM SYMPTOMS TABLE

Before replacing or repairing air conditioning components, first determine if the malfunction is due to the refrigerant charge, air flow or compressor.

STANDARD:

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

After correcting the malfunction, check the complete system to ensure that performance is satisfactory.

Symptom	Suspect Area	See page
No blower operation	1. Blower fuse	-
	2. Blower relay	HA - 62
	3. Blower motor	HA - 71, 59
	4. Power mosfet & Blower resistor	HA - 64, 67
	5. Blower speed control switch	HA - 72, 77
	6. Wire harness	-
No air temperature control	1. Engine coolant capacity	-
	2. Heater control assembly	HA - 72, 77
No compressor operation	1. Refrigerant capacity	HA - 3
	2. A/C Fuse	-
	3. Magnetic clutch	HA - 17
	4. Compressor	HA - 16
	5. A/C pressure transducer	HA - 23
	6. A/C switch	-
	7. Evaporator temperature sensor	HA - 27
	8. Wire harness	-
No cool comes out	1. Refrigerant capacity	HA - 3
	2. Refrigerant pressure	HA - 3
	3. Drive belt	-
	4. Magnetic clutch	HA - 17
	5. Compressor	HA - 16
	6. A/C pressure transducer	HA - 23
	7. Evaporator temperature sensor	HA - 27
	8. A/C switch	-
	9. Heater control assembly	HA - 72, 77
	10. Wire harness	-

GENERAL

Symptom	Suspect Area	See page
Insufficient cooling	1. Refrigerant capacity	HA - 3
	2. Drive belt	-
	3. Magnetic clutch	HA - 17
	4. Compressor	HA - 16
	5. Condenser	HA - 20
	6. Expansion valve	HA - 33
	7. Evaporator	HA - 27
	8. Refrigerant lines	HA - 25
	9. A/C pressure transducer	HA - 23
	10. Heater control assembly	HA - 72, 77
No engine idle-up when A/C	1. Engine ECM	-
switch ON	2. Wire harness	-
No air inlet control	Heater control assembly	HA - 72, 77
No mode control	1. Heater control assembly	HA - 72, 77
No cooling fan operation	1. Cooling fan fuse	-
	2. Fan motor, PWM	Refer to the group "EM"
	3. Engine ECM	-
	4. Wire harness	-

SPECIAL TOOLS EAGEE9BB

Tool (Number and name)	Illustration	Use
09977-29000 Disc & hub assembly bolt remover		Removal and installation of disc & hub assembly
	EQA9002A	

AIR CONDITIONING

INSTRUCTIONS E2DCD3CC

WHEN HANDLING REFRIGERANT

- 1. R-134a liquid refrigerant is highly volatile. A drop on the skin of your hand could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
- 2. It is standard practice to wear goggles or glasses to protect your eyes, and gloves to protect your hands. If the refrigerant splashes into your eyes, wash them with clean water immediately.
- The R-134a container is highly pressurized. Never leave it in a hot place, and check that the storage temperature is below 52 °C (126°F)
- 4. An electronic leak detector should be used to check the system for refrigerant leakage. Bear in mind that the R-134a, upon coming into contact with flame, produces phosgene, a highly toxic gas.
- 5. Use only recommended the lubricant for R-134a systems. If lubricants other than the recommended one used, system failure may occur.
- 6. PAG lubricant absorbs moisture from the atmosphere at a rapid rate, therefore the following precautions must be observed:
 - When removing refrigerant components from a vehicle, cap immediately the components to prevent from the entry of moisture.
 - When installing refrigerant components to a vehicle, do not remove the cap until just before connecting the components.
 - Complete the connection of all refrigerant tubes and hoses without delay to prevent the A/C system from taking on moisture.
 - Use the recommended lubricant from a sealed container only.

7. If an accidental discharge in the system occurs, ventilate the work area before resuming service.



LQAC003A

WHEN REPLACING PARTS ON A/C SYSTEM

- 1. Never open or loosen a connection before discharging the system.
- Seal the open fittings of components with a cap or plug immediately to prevent intrusion of moisture or dust.
- 3. Do not remove the sealing caps from a replacement component until it is ready to be installed.
- 4. Before connecting an open fitting, always install a new sealing ring. Coat the fitting and seal with refrigerant oil before making the connection.



LQAC003B

WHEN INSTALLING CONNECTING PARTS

FLANGE WITH GUIDE PIN

Check the new O-ring for damage (use only the specified) and lubricate it using compressor oil. Tighten the nut to specified torque.



LQAC003C

	Tightening torque [N·m (kg·m, lbf·ft)]			
Size	General	General bolt, nut		
	4T	7T		
M6	5 - 6 (0.5 - 0.6, 3.6 - 4.3)	9 - 11 (0.9 - 1.1, 6.5 - 7.9)		
M8	12 - 14 (1.2 - 1.4, 8.7 - 10)	20 - 26 (2.0 - 2.6, 14 - 18)		
M10	25 - 28 (2.5 - 2.8, 18 - 20)	45 - 55 (4.5 - 5.5, 32 - 39)		
Size	Flange bolt, nut			
Size	4T	7T		
M6	5 - 7 (0.5 - 0.7, 3.6 - 5.0)	8 - 12 (0.8 - 1.2, 5.8 - 8.6)		
M8	10 - 15 (1.0 - 1.5, 7 - 10)	19 - 28 (1.9 - 2.8, 14 - 20)		
M10	21 - 31 (2.1 - 3.1, 15 - 22)	39 - 60 (3.9 - 6.0, 28 - 43)		

🚺 ΝΟΤΕ

T means tensile intensity, which is stamped on the head of bolt only numeral.

HANDLING TUBING AND FITTINGS

The internal parts of the refrigeration system will remain in a state of chemical stability as long as pure moisture-free refrigerant and refrigerant oil are used. Abnormal amounts of dirt, moisture or air can upset the chemical stability and cause problems or serious damage.

THE FOLLOWING PRECAUTIONS MUST BE OBSERVED

- 1. When it is necessary to open the refrigeration system, have everything you will need to service the system ready so the system will not be left open any longer than necessary.
- 2. Cap or plug all lines and fittings as soon as they are opened to prevent the entrance of dirt and moisture.
- 3. All lines and components in parts stock should be capped or sealed until they are ready to be used.
- 4. Never attempt to rebind formed lines to fit. Use the correct line for the installation you are servicing.
- 5. All tools, including the refrigerant dispensing manifold, the gauge set manifold and test hoses, should be kept clean and dry.

AIR CONDITIONING SYSTEM

REFRIGERATION CYCLE EFAA4DA1



HEATING, VENTILATION AND AIR CONDITIONING

REFRIGERANT SYSTEM SERVICE

BASICS EEA620BA

REFRIGERANT RECOVERY

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

WARNING

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

 Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



EQBF011A



 Measure the amount of refrigerant oil removed from the A/C system after the recovery process is completed. Be sure to install the same amount of new refrigerant oil back into the A/C system before charging.

SYSTEM EVACUATION

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

- 1. When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using an R-134a refrigerant Recovery/Recycling/Charging System. (If the system has been open for several days, the receiver/dryer should be replaced, and the system should be evacuated for several hours.)
- 2. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



EQKE004A

3. If the low-pressure does not reach more than 93.3 kPa (700 mmHg, 27.6 in.Hg) in 10 minutes, there is probably a leak in the system. Partially charge the system, and check for leaks (see Leak Test.).

EQKE004A

AIR CONDITIONING SYSTEM

4. Remove the low pressure valve from the low-pressure service port.

SYSTEM CHARGING

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) as shown, following the equipment manufacturer's instructions.

REFRIGERANT LEAK TEST

Always conduct a leak test with an electronic leak detector whenever leakage or refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening or connection fittings.

🕡 ΝΟΤΕ

In order to use the leak detector properly, read the manual supplied by the manufacturer.

If a gas leak is detected, proceed as follows:

- 1. Check the torque on the connection fittings and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector (A).
- 2. If leakage continues even after the fitting has been tightened, discharge the refrigerant from the system, disconnect the fittings, and check their seating faces for damage. Always replace, even if the damage is slight.
- 3. Check the compressor oil and add oil if required.
- 4. Charge the system and recheck for gas leaks. If no leaks are found, evacuate and charge the system again.



EQKE007A



EQKE004A

2. Add the same amount of new refrigerant oil to system that was removed during recovery. Use only specified refrigerant oil. Charge the system with 18.0 ± 0.88 oz. $(510 \pm 25g)$ of R-134a refrigerant. Do not overcharge the system the compressor will be damaged.

COMPONENT LOCATION INDEX EC736D51

ENGINE ROOM



AIR CONDITIONING SYSTEM

INTERIOR



COMPRESSOR OIL

OIL SPECIFICATION E83D0838

- 1. The HFC-134a system requires synthetic (PAG) compressor oil whereas the R-12 system requires mineral compressor oil. The two oils must never be mixed.
- 2. Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.

HANDLING OF OIL

- 1. The oil should be free from moisture, dust, metal powder, etc.
- 2. Do not mix with other oil.
- The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Compressor Oil absorbs moisture very easily.)
- 4. The compressor oil must be stored in steel containers, not in plastic containers.

COMPRESSOR OIL CHECK

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

Oil total volume in system: $120 \pm 10cc (4.05 \pm 0.34 \text{ fl.oz})$

OIL RETURN OPERATION

There is close affinity between the oil and the refrigerant. During normal operation, part of the oil recirculates with the refrigerant in the system. When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows:

- 1. Open all the doors and the engine hood.
- 2. Start the engine and air conditioning switch to "ON" and set the blower motor control knob at its highest position.
- 3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
- 4. Stop the engine.

REPLACEMENT OF COMPONENT PARTS

When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

Component parts to be installed	Amount of Oil
Evaporator	50 cc (1.70 fl.oz)
Condenser	30 cc (1.02 fl.oz)
Receiver/dryer	30 cc (1.02 fl.oz)
Refrigerant line (One piece)	10 cc (0.34 fl.oz)

For compressor replacement, subtract the volume of oil drained from the removed compressor from the specified volume, and drain the calculated volume of oil from the new compressor:

The specified volume - volume of removed compressor = volume to drain from the new compressor.



Even if no oil is drained from the removed compressor, don't drain more than 50cc from new compressor.

A/C COMPRESSOR CONTROLS (MANUAL)

AIR CONDITIONING COMPRESSOR

COMPONENT LOCATION E12E246B



COMPONENTS



- 2. Disc & hub assembly
- 3. Shim (Gap washer)
- 4. Retainer ring (Pulley)
- 5. Pulley

- 7. Field coil
- 8. Screw
- 9. Connector bracket 10. Compressor assembly

EQBF105B

A/C COMPRESSOR CONTROLS (MANUAL)

REMOVAL EAE581F2

- 1. If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
- 2. Disconnect the negative cable from the battery.
- 3. Recover the refrigerant with a recovery/charging station (Refer to HA-8).
- 4. Loosen the drive belt (Refer to HA-14).
- 5. Remove the bolts, then disconnect the suction line (A) and discharge line (B) from the compressor. Plug (C) or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQBF105C

6. Disconnect the compressor clutch connector (A), and then remove 4 mounting bolts and the compressor.



KQRE105D

INSTALLATION E30FCA6C

1. Make sure of the length of compressor mounting bolts, and then tighten it $A \rightarrow B \rightarrow C \rightarrow D$ order.

Bolt	D Engine	β Engine
A	126 mm (4.96in.)	94 mm (3.70in.)
В	126 mm (4.96in.)	108 mm (4.25in.)
С	94 mm (3.70in.)	94 mm (3.70in.)
D	94 mm (3.70in.)	94 mm (3.70in.)



KQRE105E

TIGHTENING TORQUE: 2.04 ~ 3.36 kgf·m

- 2. Install in the reverse order of removal, and note these items.
 - If you're installing a new compressor, drain all the refrigerant oil from the removed compressor, and measure its volume, Subtract the volume of drained oil from 120cc(4.20 oz.) the result is the amount of oil you should drain from the new compressor (through the suction fitting).
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - To avoid contamination, do not return the oil to the container once dispensed, and never mix it with other refrigerant oils.
 - Immediately after using the oil, replace the cap on the container and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle; it may damage the paint; if the refrigerant oil contacts the paint, wash it off immediately.
 - Adjust the drive belt (Refer to HA-14)
 - Charge the system and test its performance. (Refer to HA-9)

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION E7DFDCF8

- 1. Check the plated parts of the disc & hub assembly (A) for color changes, peeling or other damage. If there is damage, replace the clutch set.
- 2. Check the pulley (B) bearing play and drag by rotating the pulley by hand. Replace the clutch set with a new one if it is noisy or has excessive play/drag.

- 4. Check operation of the magnetic clutch.
 - Connect the compressor side terminals to the battery (+) terminal and the ground battery (-) terminal to the compressor body.

Check the magnetic clutch operating noise to determine the condition.



EQBF105H

AQJF106A

 Measure the clearance between the pulley (B) and the disc & hub assembly (A) all the way around. If the clearance is not within specified limits, remove the disc & hub assembly and add or remove shim (gap washer) as needed to increase or decrease clearance.

Clearance.	0.5 ± 0.15 mm	
	0.0 ± 0.1011111	

🚺 ΝΟΤΕ

The shims (gap washers) are available in seven thicknesses: 0.7mm, 0.8mm, 0.9mm, 1.0mm, 1.1mm, 1.2mm and 1.3mm.



KQBF105G

A/C COMPRESSOR CONTROLS (MANUAL)

DISASSEMBLY EB6F1F50

- Remove the center bolt (A) while holding the disc & hub assembly with a commercially available disc & hub assembly bolt remover; Special tool number 09977-29000.
- TORQUE: 10~15N·m (1.02~1.53kgf·m, 7.37~11lbf·ft)



KQBF105I

 Remove the disc & hub assembly (A) and shim (gap washer) (B), taking care not to lose the shims. If the clutch needs adjustment, increase or decrease the number and thickness of shims as necessary, then reinstall the disc & hub assembly, and recheck its clearance (Refer to HA-19).



KQRE105J

3. If you removal the field coil, remove retainer ring (A) with retainer ring pliers.



EQKE103C

4. Remove the screw (A) from the field coil ground terminal. Remove the retainer ring (B) and then remove the field coil (C) from the shaft with a puller. Be careful not to damage the coil and compressor.



KQBF105L

- 5. Reassemble the compressor clutch in the reverse order of disassembly, and note these items :
 - Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
 - Install new retainer rings, and make sure they are fully seated in the groove.
 - Make sure that the pulley turns smoothly after its reassembled.

CONDENSER

COMPONENT LOCATION EBFE03EB



INSPECTION EC5ADDA3

- 1. Check the condenser fins for clogging and damage. If clogged, clean them with water, and blow them with compressed air. If bent, gently bend them using a screwdriver or pliers.
- 2. Check the condenser connections for leakage, and repair or replace it, if required.

REPLACEMENT EE626AAA

CONDENSER ASSEMBLY

- 1. Recover the refrigerant with a recovery/ recycling/ charging station (Refer to HA-10).
- 2. Disconnect the negative (-) battery terminal.
- 3. Remove the air duct (A) after loosening fasner.
- 4. Remove the radiator bracket (B) after loosening the bolts.



KQBF108B

5. Remove the nuts, then disconnect the dischange line and condenser line from the condenser.

🔟 ΝΟΤΕ

Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination. 6. Remove the bolts, then remove the condenser (A) by lifting it up. Be careful not to damage the radiator and condenser fins when removing the condenser.



KQBF108D

- 7. Install in the reverse order of removal, and note these items :
 - If you're installing a new condenser, add refrigerant oil ND-OIL8.
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Be careful not to damage the radiator and condenser fins when installing the condenser.
 - Be sure to install the lower mount cushions of condenser securely into the holes.
 - Charge the system, and test its performance. (Refer to HA-11)



DESICCANT

1. Remove the condenser, and then remove the bottom cap (B) with L wrench (A) from the condenser.

TORQUE: 20~25N·m (2.0~2.5kgf·m, 14.5~18.2lb·ft)



KQBF108E

2. Remove the desiccant (A) from the receiver/drier tank using a long nose plier.



KQBF108F

🚺 ΝΟΤΕ

- Always replace the desiccant and bottom cap at the same time.
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Be sure to install the lower mount cushions of condenser securely into the holes.
- Charge the system, and test its performance. (Refer to HA-11)

A/C PRESSURE TRANSDUCER

COMPONENT LOCATION EEDD623E



HA -24

DESCRIPTION E25CCF46

A/C pressure transducer convert the pressure value of high pressure line into voltage value after measure it. By converted voltage value, engine ECU controls cooling fan by operating it high speed or low speed. Engine ECU stop the operation of compressor when the temperature of refrigerant line is so high or so low irregularly to optimize air conditioning system.

INSPECTION E4FFBFAD

 Measure the pressure of high pressure line by measuring voltage output between NO.1 and NO.2 terminals.



EQRF116B

2. Inspect the voltage value whether it is sufficient to be regular value or not.

Voltage = 0100878835* Pressure + 0.5[kgf/cm²]

3. If the measured voltage value is not specification, replace the A/C pressure transducer.

Error range : + - 2.5%

REPLACEMENT E8E61C2A

- 1. Disconnect the negative (-) battery terminal
- 2. Disconnect A/C pressure transducer connector (3P) from wiring harness.



KQBF116C

🕡 ΝΟΤΕ

Take care that liquid suction pipe is not bent.

3. Installation is the reverse order of removal.

REFRIGERANT LINE

COMPONENT LOCATION E9BE4ABD



HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EBF856FE

- 1. Discharge refrigerant from refrigeration system (Refer to HA-8).
- 2. Replace faulty tube or hose.

CAUTION

Cap the open fittings immediately to keep moisture or dirt out of the system.

3. Tighten joint of bolt or nut to specified torque

Connections should not be torque tighter than the specified torque.

Part tightened	N∙m	Kgf∙m	lbf-ft
Condenser x Discharge hose			
Condenser x Liquid tube		0.5-0.6	
Compressor x Discharge hose		0.5~0.6	
Compressor x Suction hose			
Expansion valve x Evaporator		1.2~1.5	

4. Evacuate air in refrigeration system and charge system with refrigerant (Refer to HA-9).

Specified amount: 500 ± 25g

- Inspect for leakage of refrigerant. Using a gas leak detector, check for leakage of refrigerant (Refer to HA-9).
- 6. Inspect A/C operation.

HEATER

EVAPORATOR TEMPERATURE SENSOR

COMPONENT EABDE649



HEATING, VENTILATION AND AIR CONDITIONING

DESCRIPTION E7527E61

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling.

It is a negative type thermistor whose resistance is inversely proportional to temperature.

INSPECTION EC2ADC1B

- 1. Ignition " ON".
- 2. A/C switch ON.
- 3. Disconnect evaporator temprature sensor connector.
- 4. Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.

SPECIFICATION

Evaporator core temperature [℃(°F)]	Resistance [k _Ω]
-10(14)	18.31
0(32)	11.60
10(50)	7.55
15(59)	5.04
30(86)	3.44
40(104)	2.40

- 5. If the measured resistance is not specification, substitute with a known-good evaporator temperature sensor and check for proper operation.
- 6. If the problem is corrected, replace the evaporator temperature sensor.

REPLACEMENT EA18C4AE

- 1. Remove the console assembly.
- 2. Remove the crush pad center low cover (A) after loosening 2 screws.



- 3. Remove the under cover after loosening 2 screws.
- 4. Disconnect the connector pin (A).



EQRE203Z

5. Remove the evaporator temperature sensor (B) by pulling it after rotating 90° in a counterclockwise direction.



EQBF961B



EQRE161C

6. Installation is the reverse order of removal.

HEATER UNIT

COMPONENT LOCATION ED0BFF14



HEATER



- 1. Heater & Evaporator case
- 2. Heater core
- 3. Heater core cover
- 4. PTC heater (Diesel only)
- 5. Water temperature sensor
- 6. Water temperature sensor stopper
- 7. Temperature control actuator
- 8. Mode control actuator

- 9. Mode cam
- 10. Defrost door
- 11. Vent door
- 12. Floor door
- 13. Temperature control door (Single type)
- 14. Insulation
- 15. Heater & Evaporator lower case
- 16. Heater separator (Single type)

- 17. Heater separator (Dual type)
- 18. Upper case seal
- 19. Heater & Evaporator upper case
- 20. Evaporator case seal
- 21. Evaporator core
- 22. Evaporator temperature sensor
- 23. Temperature control actuator (Dual type)
- 24. Temperature control door (Dual type)

EQRF300B



- 3. Heater core cover
- 4. PTC heater (Diesel only)
- 5. Water temperature sensor
- 6. Water temperature sensor stopper
- 7. Temperature control actuator
- 8. Mode control actuator

- 11. Vent door
- 12. Floor door
- 13. Temperature control door (Single type)
- 14. Insulation
- 15. Heater & Evaporator lower case
- 16. Heater separator (Single type)
- 18. Heater & Evaporator upper case
- 19. Evaporator case seal
- 20. Evaporator core
- 21. Evaporator temperature sensor
- 22. Temperature control actuator (Dual type)
- 23. Temperature control door (Dual type)

EQRE300B

HEATER

REPLACEMENT E1BF154E

- 1. Disconnect the negative (-) battery terminal.
- 2. Recover the refrigerant with a recovery/ recycling/ charging station. (Refer to HA-10)
- 3. When the engine is cool, drain the engine coolant from the radiator.
- 4. Remove the air cleaner.
- 5. Remove the expansion valve cover(B) after loosening the nut (A).



KQRE300C

6. Remove the bolts (A) and the expansion valve (B) from the evaporator core.

Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQBF300D

7. Disconnect the inlet (A) and outlet (B) heater hoses from the heater unit.



EQRF300E

Engine coolant will run out when the hoses are disconnected; drain it into a clean drip pan. Be sure not to let coolant spill on electrical parts or painted surfaces. If any coolant spills, rinse it off immediately.

- 8. Remove the crash pad (Refer to BD group).
- 9. Remove the cowl cross bar assembly. (Refer to BD group)
- 10. Remove the heater & blower unit after loosening 3 mounting bolts.



KQBF300F

HEATING, VENTILATION AND AIR CONDITIONING

11. Remove the blower unit from heater unit(A) after loosening screws.



KQBF300G

12. Remove the heater core (B) after remove the side braket (A).

- 15. Installation is the reverse order of removal, and note these items :
 - If you're installing a new evaporator, add refrigerant oil (ND-OIL8).
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Immediately after using the oil, replace the cap on the container, and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle ; it may damage the paint ; if the refrigerant oil contacts the paint, wash it off immediately
 - Apply sealant to the grommets.
 - Make sure that there is no air leakage.
 - Charge the system and test its performance.
 - Do not interchange the inlet and outlet heater hoses and install the hose clamps securely.
 - Refill the cooling system with engine coolant



KQBF300H

- 13. Be careful that the inlet and outlet pipe are not bent during heater core removal, and pull out the heater core.
- 14. Install the heater core in the reverse order of removal.

PTC (POSITIVE TEMPERATURE COEFFICIENT) HEATER

DESCRIPTION EA61D22B

PTC (Positive Temperature Coefficient) heater (A) is an electric heater using a PTC element as an auxiliary heating device that supplements deficiency of interior heat source in highly effective diesel engine (U engine).



OPERATION PRINCIPLE

ECM outputs a PTC on signal. Operate PTC from 1st setting to 3rd setting with an interval of 15 seconds. Heat up the air, which passes through a heater core.

Connector



EQBF301C

AQJF301B

An electric heater heats up the interior by directly heating the air that passes through the heater. PTC = positive Temperature Coefficient

The name itself implies that the element has a proportional resistance change sensitive to temperature. PTC heater is installed at the exit or the backside of heater core.



AQJF301A

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION E064CF7F

Inspect the PTC operation by confirmation logic as below.

- 1. Entering method
 - 1) Set the floor mode, maximum heating
 - 2) Turn off the blower switch
 - 3) Press the intake button more than 5 times.
 - Indicator of entire button is flashed with an interval of 0.5 seconds continuously (Manual). Graphics of the entire LCD display switch on and off with an interval of 0.5 seconds continuously (Automatic)
 - Confirm the PTC operation by operating the blower switch Manual: 1~4 step, Automatic: 1~8step.
 - 6) Each PTC relay is operated with an interval of 3 seconds.
 - 7) Execute the PTC operation by confirmation logic for 30 seconds.
- 2. Cancellation method
 - 1) Select the A/C button or intake button.
 - 2) IG "OFF"
 - 3) Cancel the logic after 30 seconds automatically.
- 3. If the PTC operation is not operated, substitute with a known-good PTC and check for proper operation. If the problem is corrected, replace the PTC.
TEMPERATURE CONTROL ACTUATOR

COMPONENT LOCATION EC9B56FE



EQBF315A

HEATING, VENTILATION AND AIR CONDITIONING

DESCRIPTION EC1BD7DC

- 1. Heater unit includes mode control actuator and temperature control actuator.
- Temperature control actuator is located at the heater 2. unit. It regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temperature door by operating temperature switch and then temperature will be regulated by the hot/cold air ratio decided by position of temperature door.

INSPECTION E1E03021

- 1. Ignition "OFF".
- 2. Disconnect the connector of temperature control actuator.
- Verify that the temperature control actuator operates 3. to the hot position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
- Verify that the temperature control actuator operates 4. to the cool position when the connections in are reversed.
 - [LHD] 1 3 5 4 5 3 7 6 5. Sensor ground 1. 2. -

 - 3. Hot position
 - 4. Cool position
- 6. Feedback signal
- 7. Sensor power (5V)

EQRF315B

2

7



5. Check the voltage between terminals 5 and 6.

SPECIFICATION

Door position	Door position Voltage (5-6) (RHD:6-7)	
Max. cooling	0.3 ± 0.15V	Low voltage : 0.1V or less
Max. heating	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

- If the measured voltage is not within specification, 6. substitute with a known-good temperature control actuator and check for proper operation.
- 7. If the problem is corrected, replace the temperature control actuator.

HA -38

REPLACEMENT EB03F852

TEMPERATURE CONTROL ACTUATOR(PASSENGER'S)

1. Remove the glove box (Refer to BD group).



TEMPERATURE CONTROL ACTUATOR(DRIVER' S)

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the connector (C) of temperature control actuator.
- 3. Loosen the mounting screw and then remove the temperature control actuator(D).



KQBF315F

4. Installation is the reverse order of removal.

EQBF203G

- 2. Disconnect the temperature control actuator connector (A) after removing the air duct.
- 3. Loosen the mounting screw and then remove the temperature control actuator (B).



KQBF315D

4. Installation is the reverse order of removal.

MODE CONTROL ACTUATOR

COMPONENT LOCATION E2D35F51



EQBF316A

DESCRIPTION ED3C2ED1

The mode control actuator is located at the heater unit. It adjusts position of mode door by operating mode control actuator based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent $\rightarrow B/L \rightarrow$ floor \rightarrow mix.

INSPECTION E2C0C365

- 1. Ignition "OFF"
- 2. Disconnect the connector of mode control actuator.
- 3. Verify that the mode control actuator operates to the defrost position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
- 4. Verify that the mode control actuator operates to the vent position when connecting in the reverse.

[LHD]





EQRE316B

5. Check the voltage between terminals 5 and 6.

Door position	Voltage (5-6) (RHD:6-7)	Error detecting
Vent	0.3 ± 0.15V	Low voltage : 0.1V or less
Defrost	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

- 6. If the measured voltage is not specification, substitute with a known-good mode control actuator and check for proper operation.
- 7. If the problem is corrected, replace the mode control actuator.

REPLACEMENT ECA9BF2A

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the driver's crush pad lower panel. (Refer to BD group)
- 3. Disconnect the mode control actuator connector (A) after removing the air duct.
- 4. Loosen the mounting screws and then remove the mode control actuator (B).



KQBF316C

5. Installation is the reverse order of removal.

A/C COMPRESSOR CONTROLS (FULL AUTO)

IN CAR SENSOR

COMPONENT LOCATION E1FBD2C7



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION E2CFB8F9

- 1. In-car air temperature sensor is located at the center facia lower panel.
- 2. The sensor contains a thermistor which measures the temperature of the inside. The signal decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal the control unit regulates incar temperature to intended value.
- 3. It perceives the inside temperature, changes the resistance value, and enters the corresponding voltage into the automatic temperature control module.
- 4. It will used for discharge temperature control, sensor failsafe, temperature door control, blower motor level control, and A/C auto control.



- 1. Motor(-)
- 4. In-car sensor temp. signal
- Sensor ground (+)
 Humidity sensor signal
- 5. 5V (Vcc) 6. Motor (+)

LQJF201C

INSPECTION E4BC596B

- 1. Ignition "OFF".
- 2. Remove the in car sensor connector.
- 3. Blow air with changing temperature to the in car sensor air inlet. Measure sensor resistance between 2 and 4 terminals.
- 4. In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.



EQBF201E

SPECIFICATION

Temperature [℃(°F)]	Resistance between terminals 2and 4 ($^{k\Omega}$)		
50 (122)	10.81 ± 2.2%		
35 (95)	19.57 ± 1.6%		
25 (77)	30.00 ± 1.20%		
15 (59)	47.13 ± 1.7%		
0 (32)	97.71 ± 2.4%		
-15 (-74.2)	216.1 ± 3.2%		

🛈 ΝΟΤΕ

In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

REPLACEMENT EBFDCFE5

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia panel. (Refer to BD group).
- 3. Loosen the mounting 2 screws and then remove the in-car sensor (B).



KQBF201C

4. Installation is the reverse order of removal.

HA -44

PHOTO SENSOR

COMPONENT LOCATION E78B62FB



EQBF202A

HEATING, VENTILATION AND AIR CONDITIONING

DESCRIPTION EB4274FB

- 1. The photo sensor (A) is located at the center of defrost nozzle.
- 2. The photo sensor contains a photovoltaic (sensitive to sunlight) diode. The solar radiation received by its light receiving portion, generates an electromotive force in proportion to the amount of radiation received which is transferred to the automatic temperature control module so that the solar radiation compensation will be performed.

INSPECTION E5E3B4EB

- 1. Ignition "ON"
- 2. Using the scan tool.
- 3. Emit intensive light toward photo sensor using a lamp, and check the output voltage change.
- 4. The voltage will rise with higher intensive light and reduce with lower intensive light.

REPLACEMENT EA97E66E

- 1. Disconnect the negative (-) battery terminal.
- 2. With the (-) driver, remove the photo sensor (B) from the center of defrost nozzle (A).



KQBF202C

3. Install in the reverse order of removal.

HA -46

WATER TEMPERATURE SENSOR

COMPONENT LOCATION E2C49C2F



EQBF203A

HEATING, VENTILATION AND AIR CONDITIONING

DESCRIPTION E4A16B77

- 1. Water temperature sensor is located at the heater unit.
- 2. It detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.



INSPECTION EBAF1E08

- 1. Ignition "ON"
- Using the multi-tester, Measure resistance between 2. terminal "1" and "2" of water temperature sensor.

SPECIFICATION

Coolant temperature [℃(°F)]	Resistance (^k ^Ω)
-10(14)	55.85 ± 3%
0(32)	32.91 ± 3%
20(68)	12.51 ± 3%
40(104)	5.311 ± 3%
60(140)	2.476 ± 3%
80(176)	1.246 ± 3%



1. Water Temp Sensor (+)

EQBF203D

NOTE

2. Ground (-)

KQRE203B

Negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

HA -48

REPLACEMENT E78DEC60

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center lower side cover(A). (Refer to BD group)



KQBF203F

3. Pull the water temperature sensor (A) out at the heater unit with the stopper (B).



EQBF203E

4. Installation is the reverse order of removal.

NOTE

Take care that wire of water temperature sensor is not to be damaged.

AMBIENT TEMPERATURE SENSOR

COMPONENT LOCATION E4CCFB41



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION EA71DB9A

- The ambient temperature sensor is located at the front 1. of the condenser and detects ambient air temperature. It is a negative type thermistor; resistance will increase with lower temperature, and decrease with higher temperatures.
- The sensor output will be used for discharge temper-2. ature control, temperature regulation door control, blower motor level control, mix mode control and in-car humidity control.

NOTE

If the ambient temperature is below 2.0°C (35.6°F), the A/C compressor will be stopped.

The compressor will be operated by manual operating.



INSPECTION EE1F897D

- Ignition "OFF" 1.
- Disconnect ambient temperature sensor. 2.
- Check the resistance of ambient temperature sensor 3. between terminals 1 and 2 whether it is changed by changing of the ambient temperature.

SPECIFICATION

Ambient temperature [℃(°F)]	Resistance between terminals 1and 2 (^k Ω)
-20()	271.1 ± 3%
0 (32)	95.1 ± 3%
25()	30.0 ± 3%
50()	37.5 ± 3%
80()	3.83 ± 3%



KORE204D

REPLACEMENT EC1FDBE2

- Disconnect the negative (-) battery terminal. 1.
- 2. Remove the front bumoer under cover. (Refer to BD group)
- Remove the connector ambient temperature sensor. 3.
- 4. Loosen the mounting bolt and then remove the ambient temperature sensor.

5. Installation is the reverse order of removal.

1. Ambient Temp Sensor(+) 4. AQS Signal 5. AQS Ground (-) 2. Sensor Ground (-)

3. -

6. IG 2 (+)

EQBF204C

KQRE204B

A.Q.S (AIR QUALITY SENSOR)

COMPONENT LOCATION E493C739



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION E4A5AF33

- 1. A.Q.S is located at center support in front of the engine radiator, and detects hazardous elements in ambient air providing output signal to control.
- 2. It will detect sulfurous acid gas, carbon dioxide, carbon monoxide, hydrocarbon and allergen.

INSPECTION E6D1DB0A

1. Check the output voltage of AQS between terminals 4 and 5.

SPECIFICATION

Condition	Output signal	Fresh/recir- culation
Normal condition	4 ~ 5V	Fresh
Hazardous gas detection	0 ~ 1V	Recirculation

REPLACEMENT E59CA3CC

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the front bumper under cover. (Refer to BD group).
- 3. Remove the AQS (A) after loosening the mounting bolt.



KQBF204E

4. Installation is the reverse order of removal.



1.	Ambient Temp Sensor(+)	4.	AQS Signal
2.	Sensor Ground (-)	5.	AQS Ground (-)
3.	-	6.	IG 2 (+)

EQBF204C

HUMIDITY SENSOR

COMPONENT LOCATION EBB56AFA



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION E729B284

- 1. Humidity sensor is located at the lower crush pad and detected in-car humidity for in-car humidity control.
- 2. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity preventing in car fogging.

Air conditioner operation depends on ambient temperature and humidity.



- Motor(-)
 Sensor ground (+)
 - nd (+) 5. 5V (Vcc)
- 3. Humidity sensor signal 6. Motor (+)

LQJF201C

INSPECTION E038F490

- 1. Ignition "ON"
- 2. Using the scan tool.
- 3. Check the frequency of humidity sensor between terminals 2 and 3.
- 4. If the measured resistance is not specification, substitute with a known-good humidity sensor and check for proper operation.

Humidity (%)	Frequency between terminals 2and 3 (Hz)		
0	7351 ± 10%		
10	7224 ± 10%		
20	7100 ± 10%		
30	6979 ± 10%		
40	6853 ± 10%		
50	6728 ± 10%		
60	6600 ± 10%		
70	6468 ± 10%		
80	6330 ± 10%		
90	6186 ± 10%		
100	6033 ± 10%		

REPLACEMENT E2724A5C

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia panel (A). (Refer to BD group).
- 3. Disconnect the humidity sensor connector (A).
- 4. Loosen 2 screws and then remove the humidity sensor (B).



QJF201C

5. Installation is the reverse order of removal.



KQBF201D

BLOWER CONTROLS

BLOWER UNIT

COMPONENT LOCATION E14C3AC4



BLOWER CONTROLS

COMPONENTS



- 1. Outlet duck seal
- 2. Inlet duct case
- 3. Inlet door
- 4. Intake acuator
- 5. Air filter
- 6. Air filter housing

- 7. Blower upper case
- 8. Blower lower case
- 9. Blower seal
- 10. Blower motor
- 11. Resister(Manual)
- 12. Power mosfet(Pull auto)

EQBF351B

REPLACEMENT E672E536

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the crush pad.(Refer to BD group)
- 3. Disconnect the connectors from the intake actuator, the blower motor and power mosfet.
- 4. Remove the cowl cross bar assembly.(Refer to BD group)
- 5. Remove the heater and blower unit.



KQBF300F

6. Remove the blower unit (A) from the heater unit after loosening a mounting bolt and 3 screws.



KQBF300G

🚺 ΝΟΤΕ

Make sure that there is no air leaking out of the blower and duct joints.

7. Installation is the reverse order of removal.

HA -58

BLOWER MOTOR

COMPONENT LOCATION E3FCF63A



EQBF352A

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION E9354168

1. Connect the battery voltage and check the blower motor rotation.

[LHD]



EQBF952C

[RHD]



EQRE352C

- 2. If the blower motor does not operate properly, substitute with a known-good blower motor and check for proper operation.
- 3. If the problem is corrected, replace the blower motor.

REPLACEMENT EEFFEEA8

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the under cover after loosening 3 screws and then remove the step lamp connector (B).



KQBF352B

3. Disconnect the connector (A) of the blower motor.



AQJF352D

BLOWER CONTROLS

4. Remove the blower motor (C) after loosening the mounting screws.



KQBF352C

5. Installation is the reverse order of removal.

BLOWER RELAY

COMPONENT LOCATION E20B508B



EQBF353A

BLOWER CONTROLS

INSPECTION E52A55BE

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the passenger compartment relay box.
- There should be continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power and ground are connected to the No.16 in the I/P-D and No.13 I/P-B terminals in the passenger compartment relay box.
- 4. There should be no continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power is disconnected.

I/P-J



Terminal Position	I/P-K (9)	I/P-A (15)	l/P-D (16)	l/P-B (13)
Disconnected			\bigcirc	—0
Connected	0	\bigcirc	Θ	

EQBF323B

KTRE323A

I/P-K

I/P-L

I/P-G

I/P-F

I/P-E

I/P-D

POWER MOSFET

COMPONENT LOCATION EDAFEABA



EQBF355A

BLOWER CONTROLS

INSPECTION E692AAE7

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the power mosfet. Measure drain-to-sauce resistance of the power mosfet.



<Measurement Procedure 2>

Resistance (Drain-Sauce)		Subject		
		1	2	
Power Drain		+	-	
mosfet	Sauce	_	+	
	Normal	Ø	Approx 3M Ω	
Section	Short	Approx 0 ~ 300 Ω	Approx 0 ~ 300 Ω	
	Open	∞	∞	

- 3. If the measured resistance is not specification, replace the power mpsfet.
- 4. If measured resistance is specification, install power mosfet and ignition switch ON. Measure the voltage between blower motor terminals by operating control switch manually.

5. Select the control switch to raise voltage until high speed.



EQBF355C

SPECIFICATION

EQBF355B

Eon	Motor Voltage		
Fdii	Manual		
First speed	3.8 ± 0.5V		
Second speed	5.0 ± 0.5V		
Third speed	6.2 ± 0.5V		
Fourth speed	7.4 ± 0.5V		
Fifth speed	8.6 ± 0.5V		
Sixth speed	9.8 ± 0.5V		
Seventh speed	11.0 ± 0.5V		
eighth speed	Battery(+)		

6. If the measured voltage is not specification, substitute with a known-good power mosfet and check for proper operation.

7. If the problem is corrected, replace the power mosfet.

REPLACEMENT E1B2A46F

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the power mosfet connector (A) at the connecting part between heater and blower unit.



EQBF355D

3. Remove the power mosfet (B) after loosening the mounting screws.



KQBF355E

4. Installation is the reverse order of removal.

BLOWER RESISTOR

COMPONENT LOCATION E888CDD4



EQBF357A

HEATING, VENTILATION AND AIR CONDITIONING

HA -68

INSPECTION E668BF12

- 1. Measure terminal-to-terminal resistance of the blower resistor.
- 2. If measured resistance is not within specification, the blower resistor must be replaced. (After removing the resistor)

Terminal	2	1	4	3		
Resistance Speed ohmmeter	MH	ML	HI	LO	Resistance (Ω)	
Measurement of			0—	-0	2.9 ± 5%	
resistance between		0—	-0		1.5 ± 5%	
each terminal	0		-0		0.5 ± 5%	

EQBF357B

EQBF354C



REPLACEMENT EOB6DA8A

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the blower resistor connector (A) at the connecting part blower unit.
- 3. Remove the blower resistor after loosening the mounting screws.



KQBF357E

4. Installation is the reverse order of removal.

BLOWER CONTROLS

A/C AIR FILTER

DESCRIPTION E5EFF93E

This has particle filter which eliminates foreign materials and odor. The particle filter includes odor filter as well as conventional dust filter to ensure comfortable interior environment.

REPLACEMENT E14DF2A8

1. Open the glove box (B). Lower the glove box down completely by removing the glove box stopper (A) to the glove box.



EQBF359B

2. Remove the demper from glove box.



- 3. Remove the filter cover (A) with pushing the knob.
- 4. Replace the air filter (B), install it after making sure of the direction of air filter.



KQBF359C

🕡 ΝΟΤΕ

In case of driving in an air-polluted area or rugged terrain, check and replace the air filter as frequently as possible.

Replacement period: 15,000 km (9320 mile)

INTAKE ACTUATOR

COMPONENT LOCATION E527532E



BLOWER CONTROLS

DESCRIPTION EF525566

- 1. The intake actuator is located at the blower unit.
- 2. It regulates the intake door by signal from control unit.
- 3. Pressing the intake selection switch will shift between recirculation and fresh air modes.

INSPECTION E3A55DFA

- 1. Ignition "OFF".
- 2. Disconnect the connector of intake actuator.
- 3. Verify that the intake actuator actuator operates to the recirculation position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
- 4. Verify that the intake actuator operates to the fresh position when the connections are reversed.

[LHD]



- 2. -
- -



3. Recirculation position

4. Fresh position

6. Feedback signal

7. Sensor power (5V)

EQRF501B



EQRE501B

Door position	Voltage (5 - 6) (RHD:6-7)	Error detecting
Recirculation	0.3 ± 0.15V	Low voltage : 0.1V or less
Fresh	4.7 ± 0.15V	High voltage : 4.9V or more

- 5. If the intake actuator does not operate properly, substitute with a known-good intake actuator and check for proper operation.
- 6. If the problem is corrected, replace the intake actuator.

REPLACEMENT E4F015DB

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the glove box (Refer to BD group).
- 3. Disconnect the intake actuator connector.
- 4. Loosen the mounting screw and then remove the intake actuator (B) from the blower unit(A).



KQBF501C

5. Installation is the reverse order of removal.

BLOWER AND A/C CONTROLS (MANUAL)

CONTROL PANEL

COMPONENT EE4C16E4


BLOWER AND A/C CONTROLS (MANUAL)

CONNECTOR PIN FUNCTION

CONNECTOR	PIN	FUNCTION	
Connector (A)	1	Ground	
	2	Middle high	
	3	Middle low	
	4	High	
	5	Low	
	6	-	
Connector (B)	1	Tail lamp (+)	
	2	Battery (+)	
	3	A/C output	
	4	Vent mode	
	5	Defrost mode	
	6	Temp actuator cool	
	7	Temp actuator warm	
	8	Intake (Fresh)	
	9	Intake (Recirculation)	
	10	Rear defogger indicator	
	11	Sensor power (+ 5V)	
	12	Blower ON signal	
	13	IGN2	
	14	Tail lamp (-) : Rheostat	
	15	PTC relay 2	
	16	PTC relay 3	
	17	Temp actuator feedback signal	
	18	Mode actuator feedback signal	
	19	Intake actuator feedback signal	
	20	Evaporator temperature sensor	
	21	Blower ON signal	
	22	A/C select signal	
	23	Rear defogger switch	
	24	Sensor ground	
	25	PTC ON signal	
	26	Ground	

HEATING, VENTILATION AND AIR CONDITIONING

SCHEMATIC DIAGRAM E7BC0651





0.3P ground 24 <u>Го</u>5 ACTUATOR PHOTO 65 ц(м) Mode actuator 0.5W/B 0.3 R/B ц В თσ L L 0.30 1(LHD) 4(RHD) 0.30 REF(+5V) 0.3P 0.3P σ M43(LHD) 7 M43a(RHD) 5 M43(LHD) M43a(RHD) M-12 PHOTO 87 6(LHD 5(RHD 0.30 0.3P 0.5G/B ະ √ທ M-12 M62(LHD) M62a(RHD) 20 Sensor(+) 0.3Gr **B9M** o 0 EVAPORATOR SENSOR PHOTO 80 F/B 0.5W Temp. actuator COOL 4ω TEMPERATURE ACTUATOR ≤ 0.5Y WARM M62(LHD) 7 M62a(RHD) 5 PHOTO 80 0.30 0.3G/B A/C Select signal(High) 0.5L 0.3L A/C Switch 'ON'input 뷺 œ N 0.3P M-12 JOINT CONN-ECTOR M63(LHD) M63a(RHD) M-11 JOINT CONNECTOR PHOTO 87 0.3L ით F/B 0.5G Intake actuato 4ω 0.3Br 0.5Y 0.3Y A/C Output (High) FRE Blowe switch input 26 39 រស PHOTO 50 JC101 M51-B ≤ JE01 0.5B BLOCK PHOTO 30 REC M63(LHD) M63a(RHD) M51-B ACTUATOR PHOTO 81 ARTMENT A/C CONTROL MODULE PHOTO 69 relay control 0.3Gr œ ECU RLY FUSIBLE LINK 30A See r c. Distribution HOT AT ALL TIMES 4 C144-A A/C IP relay control 0.3Y 1 FUSE 0.5L РСМ РНОТО 29/44 40 JC101 ۰i C102 A/CON FUSE A/C COMPRESSOR PHOTO 13 A/C RELAY ENGINE COMPARTMENT BLOCK PHOTO 30

EQBF450C

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT E76BA7C8

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the crash pad center ganish(A).



3. Remove the crash pad side cover(B).



- KQBF450F
- 4. Remove the cresh pad lower panel(A).



5. Loosen the screw. Remove the center facia pannel(B) and then disconnect the connectors.



KQBF450H

6. Remove the heater & A/C controller (A) after loosening 4 screws.



KQBF450D

7. Installation is the reverse order of removal.

KQBF450G

BLOWER AND A/C CONTROLS (AUTOMATIC)

CONTROL PANEL

COMPONENT E756C38B



HEATING, VENTILATION AND AIR CONDITIONING



BLOWER AND A/C CONTROLS (AUTOMATIC)

CONNECTOR PIN FUNCTION

CONNECTOR	PIN	FUNCTION	
CONNECTOR (A)	1	Tail lamp (+)	
	2	Battery (+)	
	3	A/C output	
	4	A/C select signal	
	5	-	
	6	Diagnostic tool	
	7	-	
	8	-	
	9	Intake actuator (recirculation)	
	10	Rear defogger switch	
	11	-	
	12	IGN 2	
	13	IGN 2	
	14	Rheostat	
	15	-	
	16	Temp actuator cool(Passenger's)	
	17	Temp actuator warm(Passenger's)	
	18	Temp actuator feedback signal(Passenger's)	
	19	Vent mode	
	20	Defrost mode	
	21	Mode actuator feedback signal	
	22	Intake fresh	
	23	Intake recirculation	
	24	Intake feedback signal	
	25	Ground	
	26	Ground	

HEATING, VENTILATION AND AIR CONDITIONING

CONNECTOR	PIN	FUNCTION
CONNECTOR (B)	1	Sensor voltage (5V)
	2	AQS
	3	Ambient sensor (+)
	4	Humidity sensor (+)
	5	In car sensor (+)
	6	Evaporator temperature sensor (+)
	7	Water temperature sensor
	8	Speed sensor
	9	Power mosfet (Gate)
	10	Power mosfet (Drain)
	11	Blower motor (+)
	12	Sensor ground
	13	Temp actuator cool(Driver's)
	14	Temp actuator warm(Driver's)
	15	Photo sensor (-)(Driver's)
	16	Photo sensor (+)(Passenger's)
	17	In car motor
	18	Mode actuator feedback signal(Driver's)
	19	Blower ON signal
	20	PTC ON signal
	21	PTC relay 2
	22	PTC relay 3

BLOWER AND A/C CONTROLS (AUTOMATIC)

SELF-DIAGNOSIS EEE842DC

1. Self-diagnosis process

The F.A.T.C. module self test feature will detect electrical malfunction and provide error codes for system components with suspected failures.



🚺 NOTE

DTC data can be retrieved from the control panel directly or from the DLC using the Hi-Scan Pro.

2. How to read self-diagnostic code

After the display panel flickers three times every 0.5 second, the corresponding fault code flickers on the

FAULT CODE

setup temperature display panel every 0.5 second and will show two figures. Codes are displayed in numerical format.

Fault code			
Control unit	DTC		
00	-	Normal	
11	B1234	In-car temperature sensor open	
12	B1233	In-car temperature sensor short	
13	B1238	Ambient temperature sensor open	
14	B1237	Ambient temperature sensor short	
15	B1202	Water temperature sensor open	
16	B1203	Water temperature sensor short	
17	B1242	Evaporator temperature sensor open	
18	B1241	Evaporator temperature sensor short	
19	B1245	Temperature control actuator feed back open (Drive's)	
19	B1246	Temperature control actuator feed back short (Drive's)	
20	B2406	Temperature control actuator failure	
21	B1249	Mode control actuator open	
21	B1250	Mode control actuator short	
22	B2409	Mode control actuator failure	
23	B1200	Humidity sensor open	
24	B1201	Humidity sensor short	
25	B1208	Intake potentiometer open	
25	B1209	Intake potentiometer short	
26	B2408	Intake potentiometer failure	
27	B1257	AQS sensor open	
28	B1258	AQS sensor short	
31	B1259	AQS sensor failure	
32	B1204	Temperature control actuator open (Passenger's)	
32	B1205	Temperature control actuator short (Passenger's)	
33	B2415	Temperature control actuator failure	
33	62415		

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 3. Fault code display
 - 1) Continuance operation



HEATING, VENTILATION AND AIR CONDITIONING

5. Fail safe

NO.	ITEM	FAIL SAFE
1	In-car temperature sensor	Control with the valve of 25°C (77°F)
2	Ambient temperature sensor	Control with the valve of 20°C (67°F)
3	Evaporator temperature sensor	Control with the valve of $-2^{\circ}C$ (28.4°F)
4	Temperature sensor	Control with the valve of $-2^{\circ}C$ (28.4°F)
5	Temperature control actuator	If temperature setting 17° C - 24.5°C. Fix at maximum cooling position. If temperature setting 25° C - 32° C. Fix at maximum heating position.
6	Mode control actuator	Fix vent position, while selecting vent mode. Fix defrost position, while selecting all except vent mode.
7	Intake control actuator	Fix fresh position, while seleting fresh mode. Fix recifculation position, while selecting recirculation mode.
8	AQS sensor	Intake position : The position before selecting AQS switch.
9	Humidity sensor	Control with the value of 10%
10	Photo sensor	

BLOWER AND A/C CONTROLS (AUTOMATIC)

REPLACEMENT EC3FD3FC

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the crash pad center ganish(A).



3. Remove the crash pad side cover(B).

5. Loowen the screw. Remove the center facia pannel (A) and then disconnect the connectors.



KQBF450E

6. Remove the heater & A/C controller (A) after loosening 4 screws.



KQBF500E

KQBF450H

7. Installation is the reverse order of removal.



KQBF450F

4. Losening the screw then, remove the lower panel(A).



SCHEMATIC DIAGRAM E5B7344B



EQBF500B

BLOWER AND A/C CONTROLS (AUTOMATIC)



EQBF500C



HEATING, VENTILATION AND AIR CONDITIONING

DTC B1200 HUMIDITY SENSOR OPEN (HIGH)

COMPONENT LOCATION E55A86D0



EQBF510A

GENERAL DESCRIPTION E813CFB8

Humidity sensor located at crush pad, detects in-car humidity for in-car humidity control. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity for preventing in-car fogging. Air conditioner operation depends on ambient temperature and humidity.

DTC DESCRIPTION E26F8FC5

The A/C controller sets DTC B1200 if there is an open circuit in humidity sensor signal harness or the measured frequency value of sensor is more than threshold value(about 7,100 Hz)

DTC DETECTING CONDITION E609B0DF

ltem	Detecting Condition	Possible cause
DTC Strategy	Frequency check	Open Circuit in signal
Threshold value	• > 7,100 Hz	harnessFaulty Humidity Sensor
Detecting time	• 10msec	 Faulty A/C control unit
FAIL SAFE	Control with the value of 10%	

SPECIFICATION EF7B8179

Relative humidity(%)	Frequency(Hz)	Relative humidity(%)	Frequency(Hz)
20	7,100	60	6,600
30	6,976	70	6,468
40	6,853	80	6,330
50	6,728	90	6,186

MONITOR SCANTOOL DATA EA55BAF5

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.

1.1 DIAGNOSTIC TROUBLE CODES
B1200 HUMIDITY SENSOR - OPEN(HIGH)
NUMBER OF DTC : 1 ITEMS
PART ERAS HELP
Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1200.

EQBF510B

Are the DTC B1200 present and is parameter of "Humidity Sensor" fixed?
 * Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E5F388B6

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EE9EA63F

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure resistance between terminal "3" of Humidity Sensor and terminal "4" of A/C Control Unit.



EQBF510C

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E607AF32

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure resistance between terminal "2" of Humidity Sensor and terminal "12" of A/C Control Unit.

Specification : Approx. 0 Ω

HEATING, VENTILATION AND AIR CONDITIONING



1. Motor(-)

- 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF510D

4) Is the measured resistance within specifications?

YES

Go to "Component Inspection " procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E3A920B6

- 1. Check Humidity Sensor.
 - 1) Engine "ON"
 - 2) Connect Humidity Sensor.
 - 3) Measure Frequency between terminal "3" and "2" of Humidity sensor while increasing humidity.

Specification : Refer the specifications in fig 5.



- 1. Motor(-) 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF510E





Fig 3 : Signal waveform of Humidity sensor.

Fig 4 : Frequency of Humidity sensor Measured by scantool.



Fig 5) Specifications : Frequency value of humidity sensor as a function of Relative humidity.

EQBF510Q

4) Is the measured frequency within specifications in fig 5? (tolerance limits \pm 5%)



Go to "Check A/C Control Unit" procedure.



Substitute with a known-good Humidity sensor and check for proper operation. If the problem is corrected, replace Humidity sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

EQBF510F

- 1) Engine "ON"
- 2) Disconnect Humidity Sensor.
- 3) Measure voltage value between terminal "4" of A/C control unit and chassis ground.

Specification : 5V



EQBF510G

4) Is the measured voltage within specification?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EOFE9B19

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1201 HUMIDITY SENSOR SHORT (LOW)

COMPONENT LOCATION E7DBA350



EQBF510A

GENERAL DESCRIPTION E40CCE08

Humidity sensor located at crush pad, detects in-car humidity for in-car humidity control. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity for preventing in-car fogging. Air conditioner operation depends on ambient temperature and humidity.

DTC DESCRIPTION ED9AB2BE

The A/C controller sets DTC B1201 if there is a short circuit in humidity sensor signal harness or the measured frequency value of sensor is less than threshold value(about 6,186Hz)

DTC DETECTING CONDITION ED9D02C4

ltem	Detecting Condition	Possible cause
DTC Strategy	Frequency check	Open Circuit in power
Threshold value	• < 6,186 Hz	harnessShort Circuit in signal harnes
Detecting time	• 10msec	Faulty Humidity Sensor
FAIL SAFE	Control with the value of 10%	Faulty A/C control unit

SPECIFICATION E39EABFF

Relative humidity(%)	Frequency(Hz)	Relative humidity(%)	Frequency(Hz)
20	7,100	60	6,600
30	6,976	70	6,468
40	6,853	80	6,330
50	6,728	90	6,186

MONITOR SCANTOOL DATA E1282110

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CODES
HUMIDITY SENSOR HEATER WATER TEMP. SNSR IN-CAR TEMP. SENSOR AMBIENT AIR TEMP. SNS EVAPORATIVE SENSOR DRIVER PHOTO SENSOR AIR MIX POPENTIO. (DR.)	10 % 12.0 °C 11.0 °C 11.5 °C 12.5 °C 0.00 V 91.75 % 90 70 %	B1201 HUMIDITY SENSOR - SHORT(LOW)
FIX SCRN FULL PART GR	89.79 %	NUMBER OF DTC : 1 ITEMS
Fig. 1		Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1201.

EQBF511A

Are the DTC B1201 present and is parameter of "Humidity Sensor" fixed?
 * Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E46CEF9E

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION ECC3D1A0

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure resistance between terminal "3" of Humidity Sensor and chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Power circuit Inspection " procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION ED180193

- 1. Check for open in power harness.
 - 1) Ignition "ON"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure voltage value between terminal "5" of Humidity Sensor and chassis ground.

Specification : 5V

HEATING, VENTILATION AND AIR CONDITIONING



Motor(-)
 Sensor ground
 Humidity sensor signal
 In-car sensor temp. signal
 Sensor power (5V)
 Motor(+)

EQBF511C

4) Is the measured voltage within specifications?



Go to "Component Inspection " procedure.

NO

Check for open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E21ABF1E

- 1. Check Humidity Sensor.
 - 1) Engine "ON"
 - 2) Connect Humidity Sensor.
 - 3) Measure Frequency between terminal "3" and "2" of Humidity sensor while increasing humidity.

Specification : Refer the specifications in fig 5.



- 1. Motor(-)
- 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF510E





Fig 3 : Signal waveform of Humidity sensor.

Fig 4 : Frequency of Humidity sensor Measured by scantool.

EQBF510F

4) Is the measured frequency within specifications in fig 5? (tolerance limits \pm 5%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good Humidity sensor and check for proper operation. If the problem is corrected, replace Humidity sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure voltage value between terminal "4" of A/C control unit and chassis ground.

Specification : 5V



4. Humidity sensor signal

4) Is the measured voltage within specification?



HA -99

EQBF510G

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ECEB8038

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1202 WATER TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION ECDA84B4



EQBF512A

GENERAL DESCRIPTION E79C5561

A water temp. sensor located at heater unit, detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

DTC DESCRIPTION EFAC8202

The A/C controller sets DTC B1202 if there is an open circuit in water temp. sensor signal harness or the measured resistance value of the sensor is more than the threshold value(about $176.3k\Omega$)

DTC DETECTING CONDITION EDDA3788

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Open Circuit in harness
Threshold value	• > 176.3 kΩ	 Faulty water temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	·
FAIL SAFE	 Control with the value of -2°C(28.4°F) 	

SPECIFICATION EEDFFOBB

Temperature[°C(°F)]	Resistance(kΩ)	Temperature[°C(°F)]	Resistance(kΩ)
-30(-22)	176.3	25(77)	10
-15(5)	73.6	35(95)	6.5
0(32)	32.9	60(140)	2.5
15(59)	15.8	80(176)	1.2

MONITOR SCANTOOL DATA E23A4490

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP. SNSR -2 °C	B1202 WATER TEMP. SENS - OPEN(HIGH)
IN-CAR TEMP. SENSOR 12.0 °C	
AMBIENT AIR TEMP. SNS 11.5 °C	
EVAPORATIVE SENSOR 12.5 °C	
DRIVER PHOTO SENSOR 0.00 V	
AIR MIX POPENTIO. (DR.) 91.75 %	
DIRECTION POTENIO. DR. 54.89 %	
PASSENGER PHOTO SENSOB 255	
	NUMBER OF DTC : 1 ITEMS
FIX SCRN FULL PART GRPH HELP	PART ERAS HELP
Fig. 1	Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1202.

EQBF512B

Are the DTC B1202 present and is parameter of "WATER TEMP. SENSOR" fixed?
 ※ Parameter of "WATER TEMP. SENSOR" will be fixed at -2℃(28.4°F), if there is any fault in WATER TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EC92E599

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EE5CF56F

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "1" of water temp. sensor and terminal "7" of A/C Control Unit.





EQBF512C

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E20A6934

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "2" of water temp. sensor and chassis ground.

Specification : Approx. 0 Ω



1. Water temp. sensor signal **2. Sensor ground**

EQBF512D

4) Is the measured resistance within specifications?



Go to "Component Inspection " procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E8B1ACAD

- 1. Check water temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of water temp. sensor.

Specification : Refer the specifications in fig 3.



Water temp. sensor signal
 Sensor ground

EQBF512E

4) Is the measured resistance within specifications in fig 3)? (tolerance limits ± 3%)



Go to "Check A/C Control Unit" procedure.



Substitute with a known-good water temp. sensor and check for proper operation. If the problem is corrected, replace water temp. sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 1) Engine "ON"
- 2) Disconnect water temp. sensor.
- 3) Measure Voltage between terminal "7" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



7. Water temp. sensor signal

EQBF512F

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E60A09C9

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1203 WATER TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION E0E2BC32



GENERAL DESCRIPTION EFE4C535

A water temp. sensor located at heater unit, detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

DTC DESCRIPTION EA17C85B

The A/C controller sets DTC B1203 if there is a short circuit in water temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about $1.2k\Omega$)

DTC DETECTING CONDITION EF2E3145

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Short circuit in harness
Threshold value	• < 1.2 kΩ	 Faulty water temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of -2°C(28.4°F) 	

SPECIFICATION E6B0F9BF

Temperature[°C(°F)]	Resistance(k Ω)	Temperature[°C(°F)]	Resistance(kΩ)
-30(-22)	176.3	25(77)	10
-15(5)	73.6	35(95)	6.5
0(32)	32.9	60(140)	2.5
15(59)	15.8	80(176)	1.2

EQBF512A

MONITOR SCANTOOL DATA EADCD72B

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1203.

EQBF513A

Are the DTC B1203 present and is parameter of "WATER TEMP. SENSOR" fixed?
 ※ Parameter of "WATER TEMP. SENSOR" will be fixed at -2 ℃ (28.4°F), if there is any fault in WATER TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E4A5AB7F

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E5290ACF

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "1" of water temp. sensor and chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E688EEF4

- 1. Check water temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of water temp. sensor.

Specification : Refer the specifications in fig 3.


Water temp. sensor signal Sensor ground

EQBF512E

4) Is the measured resistance within specifications in fig 3)? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.

NO

Substitute with a known-good water temp. sensor and check for proper operation. If the problem is corrected, replace water temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect water temp. sensor.
 - 3) Measure Voltage between terminal "7" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



EQBF512F

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ED6AB445

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1204 AIR MIX POTENTIOMETER OPEN (LOW) - PASSENGER'S

COMPONENT LOCATION ECDAGCAE



EQBF521A

GENERAL DESCRIPTION E6FDAF92

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION E4F166A6

The A/C controller sets DTC B1204 if there is an open circuit or poor connection in the air mix potentiometer.

DTC DETECTING CONDITION E8DA37FC

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Poor connection of
Threshold value	• < 0.1V	connected partOpen circuit in harness
Detecting time	• 0.3 sec	Short circuit in harness
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 	Faulty driver Air Mix potentiometer



EQBF521B

MONITOR SCANTOOL DATA EF8DAA6E

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Passenger's Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1204.

EQBF521K

4. Are the DTC B1204 present and is parameter of "Passenger's Air Mix Potentiometer" fixed?
※ Parameter of "Passenger's Air Mix Potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Passenger's Air Mix potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E27080F9

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EECOTECA

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Passenger's Air Mix potentiometer.
 - Measure resistance between terminal "6" of Passenger's Air Mix Potentiometer and terminal "18" of A/C control unit.

Specification : Approx. 0 Ω



- 3. Motor
 - 4. Motor
- 5. Potentiometer ground 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

4) Is the measured resistance within specifications?



Go to "Check for short to ground in harness" procedure.

EQBF521L

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Passenger's Air Mix potentiometer.
 - 3) Measure resistance between terminal "6" of Passenger's Air Mix Potentiometer and chassis ground.

Specification : Approx. $\infty \Omega$



4) Is the measured resistance within specifications?

YES

Go to "Power circuit Inspection" procedure.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION EED3C936

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Passenger's Air Mix Potentiometer.
 - 3) Measure voltage between terminal "7" of Passenger's Air Mix Potentiometer and chassis ground.

Specification : Approx. 5V



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF521N

4) Is the measured voltage within specifications?



Go to "Component inspection" procedure.



Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E3EE5ADD

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Passenger's Air Mix Potentiometer.
 - 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3" and grounding terminal "4".
 - 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF5210

5) Does the actuator work properly?



Go to "Check potentiometer" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer

- 1) Ignition "ON"
- 2) Connect Passenger's Air Mix potentiometer.
- 3) Measure voltage between terminal "5" and "6" of Passenger's Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF521P

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E960BEBC

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1205 AIR MIX POTENTIOMETER SHORT (HIGH) - PASSENGER'S

COMPONENT LOCATION E3CE4D5C



EQBF521A

GENERAL DESCRIPTION EBBBA148

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION EEFEA86B

The A/C controller sets DTC B1205 if there is a short to power in the air mix potentiometer.

DTC DETECTING CONDITION E0C85E40

ltem	Detecting Condition Possible cause	
DTC Strategy	Voltage check	Short circuit in harness
Threshold value	• > 4.9V	Faulty driver Air Mix potentiometer
Detecting time	• 0.3 sec	
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 	



EQBF521B

MONITOR SCANTOOL DATA E7CFD25C

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Passenger's Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1205.

EQBF522F

Are the DTC B1205 present and is parameter of "Passenger's Air Mix potentiometer" fixed?
 * Parameter of "Passenger's Air Mix potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Passenger's Air Mix potentiometer.



Go to "Inspection" procedure.

NO

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E283B9EA

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E5E91EAA

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Passenger's Air Mix potentiometer.
 - 3) Measure resistance between terminal "6" and "7" of Passenger's Air Mix potentiometer.

Specification : Approx. $\infty \Omega$



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF522G

4) Is the measured resistance within specifications?



Go to "Ground circuit Inspection" procedure.

NO

Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION EE38C85A

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Passenger's Air Mix Potentiometer.
 - 3) Measure resistance between terminal "5" of Passenger's Air Mix Potentiometer and chassis ground.





- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF522H

EQBF5210

4) Is the measured resistance within specifications?



Go to "Component Inspection" procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EE9D88DB

- 1. Check actuator motor.
 - 1) Ignition "OFF"

5)

- 2) Disconnect Passenger's Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3" and grounding terminal "4".
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



Does the actuator work properly?

- 3. Motor 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

HA -121

YES

Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Passenger's Air Mix potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Passenger's Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)





EQBF521P

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ECF5DABA

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1208 INTAKE POTENTIOMETER OPEN

COMPONENT LOCATION EF749215



GENERAL DESCRIPTION EA50D8D5

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculationeives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened).

DTC DESCRIPTION E6782025

The A/C controller sets DTC B1208 if there is an open circuit or poor connection in the intake potentiometer.

DTC DETECTING CONDITION EOCD3E1C

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Poor connection of
Threshold value	• < 0.1V	Open circuit in harness
Detecting time	• 0.3 sec	Short circuit in harness
 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. Fix at fresh 		• Faulty driver intake potentiometer

SPECIFICATION E6D66101

* Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value	
Fresh	0.3±0.15V	Voltage value &< 0.08V	
Recirculation	4.7±0.15V	Voltage value &> 4.9V	

MONITOR SCANTOOL DATA EBFOEE9F

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating intake switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1208.

EQBF590C

4. Are the DTC B1208 present and is parameter of "Intake Potentiometer" fixed?
※ Parameter of "Intake Potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

YES

Go to "Inspection" procedure.



Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E0353933

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E9A2AB82

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "6" of Intake Potentiometer and terminal "24" of A/C control unit.



4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Intake potentiometer.
- 3) Measure resistance between terminal "6" of Intake Potentiometer and chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Power circuit Inspection" procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION E638022A

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Intake Potentiometer.
 - 3) Measure voltage between terminal "7"(RHD:5) of Intake Potentiometer and chassis ground.

Specification : Approx. 5V

HEATING, VENTILATION AND AIR CONDITIONING



4) Is the measured voltage within specifications?



Go to "Component inspection" procedure.



Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E4DCDE12

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
 - 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.







3. Motor

4. Motor

- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EOBE927H

5) Does the actuator work properly?



[RHD]

Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - Connect Intake potentiometer. 2)
 - Measure voltage between terminal "5"(RHD:7) and "6" of Intake potentiometer while operating Intake switch. 3)

Specification : Refer to the specifications



- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E5797203

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1209 INTAKE POTENTIOMETER SHORT

COMPONENT LOCATION E093235F



GENERAL DESCRIPTION EE9BD028

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculationeives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened).

DTC DESCRIPTION E2770B43

The A/C controller sets DTC B1209 if there is a short to power in the Intake potentiometer.

DTC DETECTING CONDITION EEE85217

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Short circuit in harness
Threshold value	• > 4.9V	 Faulty Intake potentiometer Open circuit in harness
Detecting time	• 0.3 sec	
FAIL SAFE	• Fix at fresh	

SPECIFICATION E39D5040

* Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3 ± 0.15V	Voltage value & < 0.08V
Recirculation	4.7 ± 0.15V	Voltage value & > 4.9V

MONITOR SCANTOOL DATA E43084A0

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP.SNSR14.0 °CIN-CAR TEMP.SENSOR12.0 °CAMBIENT AIR TEMP.SNS12.0 °CEVAPORATIVE SENSOR13.0 °C		B1209 INTAKE P HIGH INPUT
DRIVER PHOTO SENSOR0.00 VAIR MIX POPENTIO.(DR.)84.69 %DIRECTION POTENIO.DR.51.76 %PASSENGER PHOTO SENSOR255		
INTAKE SENSOR 100.0 %	V	NUMBER OF DTC : 1 ITEMS
FIX SCRN FULL PART GRPH HELP		PART ERAS HELP
Fig. 1		Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1209.

EQBF590D

4. Are the DTC B1209 present and is parameter of "Intake potentiometer" fixed?
※ Parameter of "Intake potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E38A07A2

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E7CCC554

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "6" and "7"(RHD:5) of Intake potentiometer.



YES

Go to "Ground circuit Inspection" procedure.

NO

Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E226B4E7

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - 3) Measure resistance between terminal "5"(RHD:7) of Intake Potentiometer and chassis ground.

HEATING, VENTILATION AND AIR CONDITIONING



4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EF55F62B

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
 - 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.



- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927H

5) Does the actuator work properly?

(-)



Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Intake potentiometer.
 - 3) Measure voltage between terminal "5"(RHD:7) and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer to the specifications

[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827I

HEATING, VENTILATION AND AIR CONDITIONING

[RHD]



3. Motor

4. Motor

5. Sensor reference voltage(+5V)

6. Potentiometer signal

7. Potentiometer ground

EQBF927I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E43701D1

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

HA -136

DTC B1233 IN-CAR TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION EB57D004



GENERAL DESCRIPTION EC43DDF5

The incar temperature sensor located at crush pad, control unit contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal, the control unit regulates incar temperature to intended value.

DTC DESCRIPTION EB63EFE3

The A/C controller sets DTC B1233 if there is a short circuit in incar temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about $7.46k\Omega$)

DTC DETECTING CONDITION E1046384

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Short circuit in harness
Threshold value	• < 7.46 kΩ	 Faulty incar temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 25°C(77°F) 	

SPECIFICATION E4823648

Temperature[°C(°F)]	Resistance(k Ω)	Temperature[°C(°F)]	Resistance(k Ω)
-30(-22)	509.57	25(77)	30
-15(5)	216.07	35(95)	15.59
0(32)	97.71	50(122)	10.81
15(59)	47.13	60(140)	7.46

MONITOR SCANTOOL DATA E2472961

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP. SNSR 13.0 °C	B1233 IN-CAR TEMP. SNSR LOW
IN-CAR TEMP. SENSOR 25.0 °C	
AMBIENT AIR TEMP. SNS 11.5 °C	
EVAPORATIVE SENSOR 12.5 °C	
DRIVER PHOTO SENSOR 0.00 V	
AIR MIX POPENTIO. (DR.) 75.68 %	
DIRECTION POTENIO. DR. 89.79 %	
PASSENGER PHOTO SENSOR 255	
	NUMBER OF DTC : 1 ITEMS
▼	
FIX SCRN FULL PART GRPH HELP	PART ERAS HELP
Fig. 1	Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1233.

EQBF514A

Are the DTC B1233 present and is parameter of "INCAR TEMP. SENSOR" fixed?
 ※ Parameter of "INCAR TEMP. SENSOR" will be fixed at 25 ℃ (77°F), if there is any fault in INCAR TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EB821E5B

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EBF88FB5

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar sensor.
 - 3) Measure resistance between terminal "4" of incar sensor and chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E6BB9B31

- 1. Check incar temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect incar sensor.
 - 3) Measure resistance between terminal "4" and "2" of incar sensor.

Specification : Refer the specifications in fig 3.

HEATING, VENTILATION AND AIR CONDITIONING



Fig 3) Specifications : Resistance value of incar temp. sensor as a function of temperature.

EQBF514G

4) Is the measured resistance within specifications in fig3? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good incar sensor and check for proper operation. If the problem is corrected, replace incar sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect incar sensor.
 - 3) Measure Voltage between terminal "5" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E5F6DCB4

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

EQBE514C

DTC B1234 IN-CAR TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION EE9B6B17



GENERAL DESCRIPTION E9F794B3

The incar temperature sensor located at crush pad, control unit contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal, the control unit regulates incar temperature to intended value.

DTC DESCRIPTION E11DE569

The A/C controller sets DTC B1234 if there is an open circuit in incar temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about $509.57k\Omega$)

DTC DETECTING CONDITION E854B0E4

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Open Circuit in harness
Threshold value	• > 509.57 kΩ	 Faulty incar temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 25°C(77°F) 	

SPECIFICATION E1AB1CCB

Temperature[°C(°F)]	Resistance(k ଯ)	Temperature[°C(°F)]	Resistance(k Ω)
-30(-22)	509.57	25(77)	30
-15(5)	216.07	35(95)	15.59
0(32)	97.71	50(122)	10.81
15(59)	47.13	60(140)	7.46

MONITOR SCANTOOL DATA E60EDB2F

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1234.

EQBF515A

Are the DTC B1234 present and is parameter of "INCAR TEMP. SENSOR" fixed?
 * Parameter of "INCAR TEMP. SENSOR" will be fixed at 25°C(77°F), if there is any fault in INCAR TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E941866C

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E1781154

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar temp. sensor.
 - 3) Measure resistance between terminal "4" of incar temp. sensor and terminal "5" of A/C Control Unit..



EQBF515B

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION EF779270

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar temp. sensor.
 - 3) Measure resistance between terminal "2" of incar temp. sensor and terminal "12" of A/C Control Unit.

Specification : Approx. 0 Ω


1. Motor(-)

- 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF515C

4) Is the measured resistance within specifications?

YES

Go to "Component Inspection " procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EB9720FD

- 1. Check incar temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect incar sensor.
 - 3) Measure resistance between terminal "4" and "2" of incar sensor.

Specification : Refer the specifications in fig 3.



- 1. Motor(-)
- 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V) 6. Motor(+)

EQBF514F



Fig 3) Specifications : Resistance value of incar temp. sensor as a function of temperature.

EQBF514G

4) Is the measured resistance within specifications in fig3? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good incar sensor and check for proper operation. If the problem is corrected, replace incar sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect incar sensor.
 - 3) Measure Voltage between terminal "5" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



- 5. Incar sensor temp. signal
- 4) Is the measured voltage within specifications?



EQBF514C

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E10F3C2D

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

AMBIENT TEMPERATURE SENSOR SHORT (LOW) **DTC B1237**

COMPONENT LOCATION ED485BBE



GENERAL DESCRIPTION E2ABCF83

The ambient temperature senor located at the center stay of the condenser, detects ambient air temperature. It is a negative type thermistor whose resistance is inversely proportional to temperature. Its output is used for discharge temperature sensor, sensor fail-safe, temperature regulation door lock, blower motor level control, mix mode control and in-car humidity control.

DTC DESCRIPTION EF007347

The A/C controller sets DTC B1237 if there is a short circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 7.48k Ω)

DTC DETECTING CONDITION E76C2039

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Short circuit in harness
Threshold value	• < 7.48kΩ	 Faulty ambient temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 20°C(68°F) 	

SPECIFICATION EA51C1AC

SPECIFICATION EA51C1AG	0		
Temperature[°C(°F)]	Resistance(k Ω)	Temperature[°C(°F)]	Resistance(kΩ)
-30(-22)	527.99	25(77)	30
-15(5)	218.21	35(95)	19.6
0(32)	97.83	50(122)	10.82
15(59)	47.12	60(140)	7.48

MONITOR SCANTOOL DATA E30FCFE7

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool.
 * Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20°C, if there is any fault in AMBIENT TEMP. SENSOR.

1.2 CURRENT DATA	1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP. SNSR IN-CAR TEMP. SENSOR17.0 °C 12.0 °CAMBIENT AIR TEMP. SNS20.0 °CEVAPORATIVE SENSOR13.0 °C DRIVER PHOTO SENSORDRIVER PHOTO SENSOR0.00 V 91.75 %DIRECTION POTENIO. (DR.)91.75 % 90.18 %PASSENGER PHOTO SENSOR255	B1237 AMBIENT TEMP. SNSR LOW NUMBER OF DTC : 1 ITEMS
FIX SCRN FULL PART GRPH HELP	PART ERAS HELP
Fig. 1	Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1237.

EQBF516B

4. Are the DTC B1237 present and is parameter of "AMBIENT TEMP. SENSOR" fixed?

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E20274CA

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EC50D358

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "1" of ambient temp. sensor and chassis ground.

Specification : Approx. ∞Ω **1. Ambient temp. sensor signal(+)** 2. Ambient temp. sensor ground 4. AQS signal input 5. AQS ground 6. AQS power

EQBF516C

4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.



Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E3B39A1B

- 1. Check Ambient temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of ambient temp. sensor.

Specification : Refer the specifications in fig 3.

E72



Fig 3) Specifications : Resistance value of ambient temp. sensor as a function of temperature.

EQBF516F

4) Is the measured resistance within specifications in fig3? (tolerance limits ±3%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good ambient temp. sensor and check for proper operation. If the problem is corrected, replace ambient temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure voltage between terminal "3" of A/C Control Unit and chassis ground.

Specification : Approx. 5V

EQBF516D

HA -152

HEATING, VENTILATION AND AIR CONDITIONING



EQBF516E

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EC81091E

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1238 AMBIENT TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION EDF1649A



GENERAL DESCRIPTION E4951473

The ambient temperature senor located at the center stay of the condenser, detects ambient air temperature. It is a negative type thermistor whose resistance is inversely proportional to temperature. Its output is used for discharge temperature sensor, sensor fail-safe, temperature regulation door lock, blower motor level control, mix mode control and in-car humidity control.

DTC DESCRIPTION EBEAF741

The A/C controller sets DTC B1238 if there is an open circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about $527k\Omega$)

DTC DETECTING CONDITION ECC7468F

ltem	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Open Circuit in harness
Threshold value	• > 527kΩ	 Faulty ambient temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 20°C(67°F) 	

SPECIFICATION E611C585

Temperature[°C(°F)]	Resistance(k Ω)	Temperature[°C(°F)]	Resistance(k Ω)
-30(-22)	527.99	25(77)	30
-15(5)	218.21	35(95)	19.6
0(32)	97.83	50(122)	10.82
15(59)	47.12	60(140)	7.48

HA -154

MONITOR SCANTOOL DATA E1C87A66

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool.
 ※ Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20℃(67°F), if there is any fault in AMBIENT TEMP. SENSOR.

1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CODE	ES
HEATER WATER TEMP. SNSR IN-CAR TEMP. SENSOR AMBIENT AIR TEMP. SNS EVAPORATIVE SENSOR DRIVER PHOTO SENSOR AIR MIX POPENTIO. (DR.) DIRECTION POTENIO. DR. PASSENGER PHOTO SENSOR	17.0 °C 12.0 °C 20.0 °C 13.0 °C 0.00 V 91.75 % 90.18 % 255		B1238 AMBIENT TEMP. SNSR HIGH	
	•	,		
FIX SCRN FULL PART GRF	PH HELP		PART ERAS	HELP
Fig. 1			Fig. 2	

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1238.

EQBF517A

4. Are the DTC B1238 present and is parameter of "AMBIENT TEMP. SENSOR" fixed?

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E7F0FB77

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

EQBF518A

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E124C6B6

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "1" of ambient temp. sensor and terminal "3" of A/C Control Unit.

Specification : Approx. 0 Ω



4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION EA9F4A89

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "2" of ambient temp. sensor and chassis ground.

Specification : Approx. 0 Ω

HEATING, VENTILATION AND AIR CONDITIONING



Ambient temp. sensor signal(+)
 Ambient temp. sensor ground
 AQS signal input
 AQS ground
 AQS power

EQBF518B

4) Is the measured resistance within specifications?



Go to "Component Inspection " procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E513CAB3

- 1. Check Ambient temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of ambient temp. sensor.

Specification : Refer the specifications in fig 3.



- 1. Ambient temp. sensor signal
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF516D



Fig 3) Specifications : Resistance value of ambient temp. sensor as a function of temperature.

EQBF516F

EQBF516E

4) Is the measured resistance within specifications in fig3? (tolerance limits $\pm 3\%$)

YES

Go to "Check A/C Control Unit" procedure.

NO

Substitute with a known-good ambient temp. sensor and check for proper operation. If the problem is corrected, replace ambient temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure voltage between terminal "3" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



- 3. Ambient temp. sensor signal
- 4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E58CEDF6

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1241 EVAPORATOR TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION E486BCF6



EQBF519A

GENERAL DESCRIPTION E8813265

The Evaporator temperature sensor located on heater unit, detects the core temperature and interrupts compressor relay power, in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

DTC DESCRIPTION E059C248

The A/C controller sets DTC B1241 if there is a short circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about $0.9k\Omega$)

DTC DETECTING CONDITION E71F012F

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Short circuit in harness
Threshold value	• < 0.9kΩ	 Faulty Evaporator temp. Sensor
Detecting time	• 0.3 sec	 Faulty A/C control unit
FAIL SAFE	 Control with the value of -2°C(28.4°F) 	

SPECIFICATION E8COABD9

* Resistence value of evaporator sensor as a function of temperature.

Temperature[°C(°F)]	Resistance(k Ω)	Temperature[°C(°F)]	Resistance(k Ω)
-10(14)	13.6	15(59)	3.9
0(32)	8	30(86)	2
5(41)	6.2	40(104)	1.3
10(50)	4.9	50(122)	0.9

HA -160

MONITOR SCANTOOL DATA E6823FFB

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP. SNSR 13.0 °C		B1241 EVAP. SENSOR - LOW INPUT
IN-CAR TEMP. SENSOR 12.0 °C		
AMBIENT AIR TEMP. SNS 12.0 °C		
EVAPORATIVE SENSOR -2.0 °C		
DRIVER PHOTO SENSOR 0.00 V		
AIR MIX POPENTIO. (DR.) 91.75 %		
DIRECTION POTENIO. DR. 90.18 %		
PASSENGER PHOTO SENSOR 255		
		NUMBER OF DTC : 1 ITEMS
	▼	
FIX SCRN FULL PART GRPH HELF	•	PART ERAS HELP
Fig. 1		Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1241.

EQBF519B

Are the DTC B1241 present and is parameter of "EVAPORATIVE SENSOR" fixed?
 * Parameter of "EVAPORATIVE SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in EVAPORATIVE SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EAF84DC8

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EAF42A6E

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" of evaporator temp. sensor and chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EB45B875

- 1. Check evaporator temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of evaporator temp. sensor.

Specification : Refer the specifications in fig 3.



Fig 3) Specifications : Resistance value of evaporator temp. sensor as a function of temperature.

EQBF519F

4) Is the measured resistance within specifications in fig3? (tolerance limits $\pm 3\%$)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good evaporator temp. sensor and check for proper operation. If the problem is corrected, replace evaporator temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure voltage between terminal "6" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



EQBF519E

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E32624E3

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1242 EVAPORATOR TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION EB9F7C1F



GENERAL DESCRIPTION E073E679

The Evaporator temperature sensor located on heater unit, detects the core temperature and interrupts compressor relay power, in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

DTC DESCRIPTION E9354B2A

The A/C controller sets DTC B1242 if there is an open circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about $13.6k\Omega$)

DTC DETECTING CONDITION E61B9B78

ltem	Detecting Condition		Possible cause
DTC Strategy	Resistance check		Open Circuit in harness
Threshold value	• > 13.6kΩ		 Faulty Evaporator temp. Sensor
Detecting time	• 0.3 sec		 Faulty A/C control unit
FAIL SAFE	 Control with the value of -2°C(28.4°F) 		

SPECIFICATION E70F7716

Temperature[°C(°F)]	Resistance(k ଯ)	Temperature[°C(°F)]	Resistance(kΩ)
-10(14)	13.6	15(59)	3.9
0(32)	8	30(86)	2
5(41)	6.2	40(104)	1.3
10(50)	4.9	50(122)	0.9

EQBF519A

MONITOR SCANTOOL DATA E1C7971C

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1242.

EQBF520A

Are the DTC B1242 present and is parameter of "EVAPORATIVE SENSOR" fixed?
 * Parameter of "EVAPORATIVE SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in EVAPORATIVE SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E2790250

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EE8145E7

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" of evaporator temp. sensor and terminal "6" of A/C Control Unit.



4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION EDTACE72

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "2" of evaporator temp. sensor and chassis ground.

Specification : Approx. 0 Ω



- 1. Evaporator temp. sensor signal
- 2. Evaporator temp. sensor ground

EQBF520C

4) Is the measured resistance within specifications?



Go to "Component Inspection " procedure.



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EAB63ADA

- 1. Check evaporator temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of evaporator temp. sensor.

Specification : Refer the specifications in fig 3.



- 1. Evaporator temp. sensor signal
- 2. Evaporator temp. sensor ground

EQBF519D



Fig 3) Specifications : Resistance value of evaporator temp. sensor as a function of temperature.

EQBF519F

4) Is the measured resistance within specifications in fig3? (tolerance limits $\pm 3\%$)

YES

Go to "Check A/C Control Unit" procedure.

NO

Substitute with a known-good evaporator temp. sensor and check for proper operation. If the problem is corrected, replace evaporator temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure voltage between terminal "6" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



HA -169

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E70127E7

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B1245 AIR MIX POTENTIOMETER OPEN (LOW) - DRIVER

COMPONENT LOCATION E719A3CD



EQBF522E

GENERAL DESCRIPTION E1CAAD32

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION E60167C1

The A/C controller sets DTC B1245 if there is an open circuit or poor connection in the air mix potentiometer.

DTC DETECTING CONDITION E5EC5C4F

ltem	Detecting Condition	Possible cause	
DTC Strategy	Voltage check	 Poor connection of connected part Open circuit in harness Short circuit in harness 	
Threshold value	• < 0.1V		
Detecting time	• 0.3 sec		
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 	Faulty driver Air Mix potentiometer	



EQBF521B

MONITOR SCANTOOL DATA ED7CC1EA

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1245.

EQBF521C

Are the DTC B1245 present and is parameter of "Driver Air Mix Potentiometer" fixed?
 * Parameter of "Driver Air Mix Potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.



Go to "Inspection" procedure.

NO

HA -172

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E3032942

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EC98F659

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix potentiometer.
 - 3) Measure resistance between terminal "6" of Driver Air Mix Potentiometer and terminal "18" of A/C control unit.

Specification : Approx. 0 Ω



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF821D



EQBF921D

4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"

Specification : Approx.

2) Disconnect Driver Air Mix potentiometer.

Ω∞

3) Measure resistance between terminal "6" of Driver Air Mix Potentiometer and chassis ground.

[LHD] 3. Motor M35 * 4. Motor 3 7 5 4 6 5. Sensor reference voltage(+5V) 6. Potentiometer signal 7. Potentiometer ground EQBF821E [RHD] 3. Motor M35 4. Motor 4 3 5 6 5. Potentiometer ground 6. Potentiometer signal 7. Sensor reference voltage(+5V)

YES

Go to "Power circuit Inspection" procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION E2387022

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix Potentiometer.
 - 3) Measure voltage between terminal "7"(RHD:5) of Driver Air Mix Potentiometer and chassis ground.

Specification : Approx. 5V



Go to "Component inspection" procedure.

NO

Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EFB9A59D

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Potentiometer.
 - 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
 - 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



5) Does the actuator work properly?



Go to "Check potentiometer" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix potentiometer.
 - 3) Measure voltage between terminal "6" and "7" of Driver Air Mix potentiometer while operating the temp. switch.

HA -176

HEATING, VENTILATION AND AIR CONDITIONING



 Door position
 Voltage (3-4)
 Error detecting

 MAX. Cooling
 0.3 ± 0.15V
 Low voltage : 0.08V or less

 MAX. Heating
 4.7 ± 0.15V
 High voltage : 4.9V or more



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E883B840

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1246 AIR MIX POTENTIOMETER SHORT (HIGH) - DRIVER

COMPONENT LOCATION E3948C9B



EQBF522E

GENERAL DESCRIPTION E8B15D5D

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION ECABD6D9

The A/C controller sets DTC B1246 if there is a short to power in the air mix potentiometer.

DTC DETECTING CONDITION E946FDCA

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	 Short circuit in harness Faulty driver Air Mix potentiometer
Threshold value	• > 4.9V	
Detecting time	• 0.3 sec	
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 	



EQBF521B

MONITOR SCANTOOL DATA E0F5D9A1

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1246.

EQBF522A

Are the DTC B1246 present and is parameter of "Driver Air Mix potentiometer" fixed?
 * Parameter of "Driver Air Mix potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.



Go to "Inspection" procedure.

NO

HA -180

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EFE9FA90

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EC608CD7

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix potentiometer.
 - 3) Measure resistance between terminal "6" and "5" of Driver Air Mix potentiometer.

Specification : Approx. $\infty \Omega$

[LHD] 3. Motor M35 * 4. Motor 3 5 4 6 5. Sensor reference voltage(+5V) 6. Potentiometer signal 7. Potentiometer ground EQBF822B [RHD] M35 3. Motor 4. Motor 7 6 5 4 3 5. Potentiometer ground 6. Potentiometer signal 7. Sensor reference voltage(+5V)

EQBF922B
YES

Go to "Ground circuit Inspection" procedure.

NO

Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E4163DA5

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Potentiometer.
 - 3) Measure resistance between terminal "7"(RHD:5) of Driver Air Mix Potentiometer and chassis ground.



Go to "Component Inspection" procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E74FBEDE

1. Check actuator motor.

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



YES

Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix potentiometer.
 - 3) Measure voltage between terminal "6" and "7" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)

HA -182



 Door position
 Voltage (3-4)
 Error detecting

 MAX. Cooling
 0.3 ± 0.15V
 Low voltage : 0.08V or less

 MAX. Heating
 4.7 ± 0.15V
 High voltage : 4.9V or more



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

HA -183

4) Is the measured voltage within specifications in fig3?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EB8C6BA5

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1249 DIRECTION POTENTIOMETER OPEN (LOW) - DRIVER

COMPONENT LOCATION E1A16B4D



GENERAL DESCRIPTION E25C3DBB

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent \rightarrow B/L \rightarrow floor \rightarrow mix.

DTC DESCRIPTION E2F32A26

The A/C controller sets DTC B1249 if there is an open circuit or poor connection in the Direction potentiometer.

DTC DETECTING CONDITION E699D917

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Poor connection of
Threshold value	• < 0.1V	connected partOpen circuit in harness
Detecting time	• 0.3 sec	Short circuit in harness
FAIL SAFE	Fix vent position, while selecting vent mode.Fix defrost position while selecting except vent mode.	Faulty driver direction potentiometer



EQBF523B

MONITOR SCANTOOL DATA E63388EE

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1249.

EQBF523C

Are the DTC B1249 present and is parameter of "DR. DIRECTION POTENTIO." fixed?
 * Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E3E72485

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EEDADDD6

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "6" of Driver Direction potentiometer and terminal "21" of A/C control unit.

Specification : Approx. 0 Ω



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF823D

HEATING, VENTILATION AND AIR CONDITIONING



Motor
 Motor

5. Sensor reference voltage(+5V)

6. Potentiometer signal

7. Potentiometer ground

EQBF923D

4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

*

7

- 1) Ignition "OFF"
- 2) Disconnect Driver mode Actuator.
- 3) Measure resistance between terminal "6" of Driver Direction potentiometer and chassis ground.

Specification : Approx. ∞ Ω

M29

*

3

5 4

- 3. Motor
- 4. Motor
- 5. Potentiometer GND
- 6. Potentiometer signal
- 7. Sensor REF +5V

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor REF +5V
- 6. Potentiometer signal
- 7. Potentiometer GND

EQBF923E

EQBF823E

YES

Go to "Power circuit Inspection" procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION E7CE5F7A

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "7"(RHD:5) of Driver Direction potentiometer and chassis ground.



4) Is the measured voltage within specifications?



Go to "Component Inspection" procedure.

NO

Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E1CCOBF4

- 1. Check actuator.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Direction potentiometer.
 - 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
 - 4) Verify that the mode actuator operates to the def mode when the connections are reversed.



5) Does the actuator work properly?



Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "5"(RHD:7) and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3



EQBF923I

Door position	Voltage (3-4)	Error detecting
VENT	0.3 ± 0.15V	Under voltage : 0.08V or less Over voltage : 4.92V or more
BI-LEVEL(1)	1.35 ± 0.4V	
BI-LEVEL(2)	2.25 ± 0.4V	
FLOOR	$3.0 \pm 0.4 V$	
MIX	3.6 ± 0.4V	
DEF	4.7 ± 0.15V	



Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure. NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E17B27B5

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1250 DIRECTION POTENTIOMETER SHORT (HIGH) - DRIVER

COMPONENT LOCATION EAAF06F7



EQBF523A

GENERAL DESCRIPTION E42DB595

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent \rightarrow B/L \rightarrow floor \rightarrow mix.

DTC DESCRIPTION E506ACD5

The A/C controller sets DTC B1250 if there is a short to power in the Direction potentiometer.

DTC DETECTING CONDITION E6521921

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Short circuit in harness
Threshold value	• > 4.9V	 Faulty driver direction potentiometer
Detecting time	• 0.3 sec	Open circuit in harness
FAIL SAFE	Fix vent position	



EQBF523B

MONITOR SCANTOOL DATA E6C26D12

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1250.

EQBF524A

Are the DTC B1250 present and is parameter of "DR. DIRECTION POTENTIO." fixed?
 * Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E7C9EC9A

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EBA6FBEC

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "6" and "7"(RHD:5)of Driver Direction potentiometer.

Specification : Approx. $\infty \Omega$



YES

Go to "Ground circuit inspection" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E64B7078

- 1. Check for open in ground harnesS.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "5"(RHD:7) of evaporator sensor and chassis ground.



NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E48D945D

1. Check actuator.

- 1) Ignition "OFF"
- 2) Disconnect Driver Direction potentiometer.
- 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the mode actuator operates to the def mode when the connections are reversed.



5) Does the actuator work properly?

YES

Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "5"(RHD:7) and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3

HEATING, VENTILATION AND AIR CONDITIONING



Door position Voltage (3-4) Error detecting VENT 0.3 ± 0.15V BI-LEVEL(1) $1.35 \pm 0.4V$ BI-LEVEL(2) $2.25 \pm 0.4V$ Under voltage : 0.08V or less Over voltage : 4.92V or more $3.0 \pm 0.4V$ FLOOR MIX $3.6 \pm 0.4V$ DEF 4.7 ± 0.15V



Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E41A230A

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1257 AQS OPEN

COMPONENT LOCATION EF8D2F76



EQBF530A

GENERAL DESCRIPTION ED4DF3B0

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

DTC DESCRIPTION E12FB0BD

The A/C controller sets DTC B1257 if there is an open circuit in AQS sensor signal harness or the measured voltage value of sensor is more than threshold value.

DTC DETECTING CONDITION EB1B1045

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Open Circuit in power
Threshold value	• > 4.9V	harnessOpen circuit in ground
Detecting time	• 1 sec	harness
FAIL SAFE	 AQS function OFF Intake door : return to previous state 	 Faulty AQS Sensor Poor connection of connected part

SPECIFICATION ECC6418A

* Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)

Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

MONITOR SCANTOOL DATA EA426CBE

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor " Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1257.

EQBF590B

4. Are the DTC B1257 present and is parameter of "AQS SENSOR" fixed?



Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E078D7E2

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EF29F40C

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "4" of AQS sensor and terminal "2" of A/C Control Unit.

Specification : Approx. 0 Ω



EQBF531B

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E60583A8

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "5" of AQS sensor and chassis ground.

Specification : Approx. 0 Ω



- Ambient temp. sensor(+)
 Ambient temp. sensor ground
 AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF531C

4) Is the measured resistance within specifications?



Go to "Component Inspection " procedure.

NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E0F5764B

- 1. Check AQS sensor.
 - 1) Engine "ON"
 - 2) Connect AQS sensor.
 - 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer to the specifications.



- 1. Ambient temp. sensor(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with AQS sensor and check for proper operation. If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EF0A99CE

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1258 AQS SHORT

COMPONENT LOCATION ETAE9C53



GENERAL DESCRIPTION E78FDD65

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

DTC DESCRIPTION E65E21A7

The A/C controller sets DTC B1258 if there is a short circuit in AQS sensor signal harness or the measured voltage value of the sensor is less than the threshold value.

DTC DETECTING CONDITION E862F7F5

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Short circuit in harness
Threshold value	• < 0.1V	 Faulty AQS Sensor Fault A/C Control Unit
Detecting time	• 1 sec	
FAIL SAFE	 AQS function OFF Intake door : return to previous state 	

SPECIFICATION EBC31DE0

* Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

MONITOR SCANTOOL DATA EB72B2D9

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor" Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.

1.2 CURRENT DATA	1.1 DIAGNOSTIC TROUBLE CODES	
HEATER WATER TEMP. SNSR14.0IN-CAR TEMP. SENSOR12.0AMBIENT AIR TEMP. SNS12.0EVAPORATIVE SENSOR13.0DRIVER PHOTO SENSOR0.00AIR MIX POPENTIO. (DR.)84.69DIRECTION POTENIO. DR.51.76	°C ▲ °C °C °C °C V 9 % 6 %	
AOS SENSOR	NUMBER OF DTC : 1 ITEMS	
FIX SCRN FULL PART GRPH H	IELP PART ERAS HELP	'
Fig. 1	Fig. 2	

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1258.

EQBF590A

4. Are the DTC B1258 present and is parameter of "AQS SENSOR" fixed?

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C control unit's connector or was repaired and A/C control unit memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EA2C2E51

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E0460C72

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "4" of AQS sensor and terminal chassis ground.



4) Is the measured resistance within specifications?

YES

Go to "Component inspection" procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E2A85239

- 1. Check AQS sensor.
 - 1) Engine "ON"
 - 2) Connect AQS sensor.
 - 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer the specifications.

HEATING, VENTILATION AND AIR CONDITIONING



Ambient temp. sensor(+)
 Ambient temp. sensor ground
 AQS signal input
 AQS ground
 AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.



Substitute with a AQS sensor and check for proper operation. If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine : "ON"
 - 2) Disconnect AQS sensor.
 - 3) Measure voltage between terminal "2" of A/C Control Unit and chassis ground.

Specification : Approx. 5V





EQBF530E

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is correcirculationted, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E37705AF

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

DTC B1259 AQS FAILURE

COMPONENT LOCATION E898B5F4



EQBF530A

GENERAL DESCRIPTION EB944E6D

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

DTC DESCRIPTION E1DFB9E8

The A/C controller sets DTC B1259 if preheating time of AQS sensor is over 40sec or signal from AQS sensor is not within specifications.

DTC DETECTING CONDITION E734CCDD

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage/time check	 Faulty AQS Sensor
Threshold value	 Voltage : Preheating - 2.5V±0.3V Normal - 4.3V±0.3V Gas detected - 0.9V±0.3V Preheating time > 40sec 	Poor connection of connected part
Detecting time	-	
FAIL SAFE	 AQS function OFF Intake door : return to previous state 	

SPECIFICATION E441620B

* Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

MONITOR SCANTOOL DATA E226D7AB

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor " Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CODES
HEATER WATER TEMP. SNSR1IN-CAR TEMP. SENSOR1AMBIENT AIR TEMP. SNS1EVAPORATIVE SENSOR1DRIVER PHOTO SENSOR0AIR MIX POPENTIO. (DR.)8DIRECTION POTENIO. DR.5PASSENGER PHOTO SENSOR2AQS SENSOR2	14.0 °C 12.0 °C 12.0 °C 13.0 °C 0.00 V 34.69 % 51.76 % 255 2.6 V	B1259 AQS SENSOR FAULT NUMBER OF DTC : 1 ITEMS
FIX SCRN FULL PART GRP	H HELP	PART ERAS HELP
Fig. 1		Fig. 2

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1259.

EQBF517B

4. Are the DTC B1259 present and is parameter of "AQS SENSOR" fixed?

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EFA337DB

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E3C76BFD

- 1. Check for open in harness.
 - 1) Ignition "ON"
 - 2) Disconnect AQS sensor.
 - 3) Measure voltage value between terminal "6" of AQS sensor and chassis ground.

Specification : Approx. 12V



Ambient temp. sensor(+)
 Ambient temp. sensor ground
 AQS signal input
 AQS ground
 AQS power

EQBF532C

4) Is the measured resistance within specifications?

YES

Go to "Component inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E81F882D

- 1. Check AQS sensor.
 - 1) Engine "ON"
 - 2) Connect AQS sensor.
 - 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer the specifications.



- Ambient temp. sensor(+)
 Ambient temp. sensor ground
 AQS signal input
 AQS ground
- 6. AQS power
- 5. AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a AQS sensor and check for proper operation. If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E5CA9EEA

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B2406 AIR MIX MOTOR (DRIVER)

COMPONENT LOCATION EFE0376F



EQBF521A

GENERAL DESCRIPTION E64AC948

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION E2ABFEF5

The A/C controller sets DTC B2406 if the air mix actuator doesn't move to intended position within 40sec (In this case, A/C controller try to move temp. door for 2sec. 3 times, every 20 sec. before setting DTC).

DTC DETECTING CONDITION EA8F2B90

ltem	Detecting Condition	Possible cause	
DTC Strategy	Voltage check	 Poor connection of connected part Open circuit in harness 	
Threshold value	• < 0.1V		
Detecting time	• 0.3 sec	 Short circuit in harness Faulty driver Air Mix potentiometer Fault A/C Control Unit 	
FAIL SAFE	-		



EQBF521B

MONITOR SCANTOOL DATA E41751B0

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B2406.

EQBF525A

Are the DTC B2406 present and is parameter of "Driver AIR MIX Potentiometer" fixed?
 * There is any fault in Driver AIR MIX Motor. If the parameter of "Driver AIR MIX DOOR" is 30% or less when the actuator operates to the hot position, or If the parameter is 60% and more when the actuator operates to the cold position.



Go to "Inspection" procedure.



HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E7F42C7B

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EAE92A03

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix potentiometer.
 - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and terminal "16,17" of A/C control unit.

Specification : Approx. 0 Ω



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF825B


3. Motor

4. Motor

- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF925B

4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.

Specification : Approx. $\infty \Omega$

[LHD]



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF825C





3. Motor

- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

4) Is the measured resistance within specifications?



Go to "Visual/Physical Inspection " procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

VISUAL/PHYSICAL INSPECTION E991C1F7

- Check actuator.
 * Check if Driver Air Mix Actuator works properly through ACTUATION TEST.
 - 1) Ignition : ON
 - 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

1.	3 ACTUATION TEST	
DRIVER A	AIR MIX DOOR - DRIVE 50%	
DURATION	UNTIL STOP KEY	
METHOD	ACTIVATION	
CONDITION	IG. KEY ON ENGINE RUNNING	
PRESS [S	TRT], IF YOU ARE READY!	
STRT STOP		

Fig. 3

Fig 3 : Selecting "ACTUATION TEST" mode.

3) Does Driver Air Mix Actuator work properly?



Go to "Component Inspection" procedure.

NO

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E076DD0D

- 1. Check actuator motor.
 - 1) Ignition "OFF"

EQBF525D

- 2) Disconnect Driver Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



5) Does the actuator work properly?

YES

Go to "Check potentiometer" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)

HA -220

HEATING, VENTILATION AND AIR CONDITIONING



 Door position
 Voltage (3-4)
 Error detecting

 MAX. Cooling
 0.3 ± 0.15V
 Low voltage : 0.08V or less

 MAX. Heating
 4.7 ± 0.15V
 High voltage : 4.9V or more



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 3. Check A/C Control Unit.
 - 1) Engine "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "16" and "17" of A/C Control Unit while operating the temp. switch.

Specification : Approx. 12V



EQBF525E

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E9F02EC4

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B2408 INTAKE MOTOR FAILURE

COMPONENT LOCATION EFIAEBER



GENERAL DESCRIPTION EBF43D13

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculationeives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened.

DTC DESCRIPTION EDEFA576

The A/C controller sets DTC B2408 if the intake motor Doesn't move to intended position within 40sec(The A/C controller attempts to move the intake door for a 2 second duration at a freshquency of 3 times every 20 seconds before storing a DTC.)

DTC DETECTING CONDITION E70DC6B0

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Poor connection of
Threshold value	• < 0.1V	connected partOpen circuit in harness
Detecting time	• 0.3 sec	Short circuit in harness
FAIL SAFE	-	Faulty Intake potentiometer

SPECIFICATION E6B3190E

* Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3±0.15V	Voltage value 0.08V or less
Recirculation	4.7±0.15V	Voltage value 4.9V or more

MONITOR SCANTOOL DATA E73BFCC6

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B2408.

EQBF529A

Are the DTC B2408 present and is parameter of "Intake Potentiometer" fixed?
 There is any fault in Intake potentiometer. If the parameter of "Intake potentiometer" is 30% or less when the actuator operates to the fresh position, or If the parameter is 60% and more when the actuator operates to the recirculation position.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EDCEF15E

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EODD314B

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "3,4" of Intake potentiometer and terminal "22,23" of A/C control unit.



4) Is the measured resistance within specifications?



Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.

Specification : Approx. $\infty \Omega$



4) Is the measured resistance within specifications?

YES

Go to "Visual/Physical Inspection " procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

VISUAL/PHYSICAL INSPECTION E43EAB6A

1. Check actuator.

* Check if Driver Air Mix Actuator works properly through ACTUATION TEST.

- 1) Ignition : ON
- 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

HA -226

1.	3 ACTUATION TEST		
DRIVER AIR MIX DOOR - DRIVE 50%			
DURATION	DURATION UNTIL STOP KEY		
METHOD	ACTIVATION		
CONDITION	IG. KEY ON ENGINE RUNNING		
PRESS [STRT], IF YOU ARE READY!			
STRT STOP			
Fig. 3			

Fig 3 : Selecting "ACTUATION TEST" mode.

EQBF525D

3) Does Intake Actuator work properly?

YES

Go to "Component Inspection" procedure.

NO

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EC3D4A88

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
 - 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.







3. Motor

4. Motor

- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927H

5) Does the actuator work properly?



[RHD]

Go to "Check potentiometer" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Intake potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer the specifications

[LHD] 3. Motor M37 * * 4. Motor 7 4 3 6 5 5. Potentiometer ground 6. Potentiometer signal 7. Sensor reference voltage(+5V) EQBF827I [RHD] 3. Motor M37 * 4. Motor 6 5 4 3

5. Sensor reference voltage(+5V)

- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 3. Check A/C Control Unit.
 - 1) Engine "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "22" and "23" of A/C Control Unit while operating the Intake switch.

Specification :Approx. 12V



EQBF529E

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EODD17DE

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

DTC B2409 DIRECTION CONTROL MOTOR (DRIVER)

COMPONENT LOCATION E106240B



EQBF523A

GENERAL DESCRIPTION EF5781CF

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent \rightarrow B/L \rightarrow floor \rightarrow mix.

DTC DESCRIPTION EC2E4DF8

The A/C controller sets DTC B2409 if the direction motor doesn't move to intended position within 40sec(In this case, A/C controller try to move mode door for 2sec. 3 times, every 20 sec. before setting DTC).

DTC DETECTING CONDITION EC90DC02

ltem	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Poor connection of
Threshold value	• < 0.1V	connected partOpen circuit in harness
Detecting time	• 0.3 sec	Short circuit in harness
FAIL SAFE	-	 Faulty driver direction potentiometer Fault A/C Control Unit.

E463272E

4.7V Output voltage 2.5V 0.3V DEF Direction Potentiometer VENT

EQBF523B

MONITOR SCANTOOL DATA E65417DD

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"

SPECIFICATION

3. Monitor the "DR DIRECTION POTENTIO" parameter on the scantool while operating mode switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B2409.

EQBF526A

Are the DTC B2409 present and is parameter of "Driver DIRECTION POTENTIO." fixed?

 * There is any fault in Driver Direction Motor. If the parameter of "Driver DIRECTION POTENTIO." is 10% or less on "VENT" mode, or If the parameter is 90% or more on "DEF" mode.



Go to "Inspection" procedure.



HA -231

NO

HA -232

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E445635C

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E1953B5C

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Direction Motor and terminal "19,20" of A/C control unit.

Specification : Approx. 0 Ω



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF826B



3. Motor

4. Motor

- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF926B

4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Direction Motor and chassis ground.

Specification : Approx. $\infty \Omega$

[LHD]



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF826C

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

4) Is the measured resistance within specifications?



Go to "Visual/Physical Inspection " procedure.

NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

VISUAL/PHYSICAL INSPECTION E50E56B6

- Check actuator.
 * Check if Driver Direction Actuator works properly through ACTUATION TEST.
 - 1) Ignition : ON
 - 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

1.	3 ACTUATION TEST	
DRIVER AIR OUTLET MODE-DRIVE FOOT		
DURATION	UNTIL STOP KEY	
METHOD	ACTIVATION	
CONDITION	IG. KEY ON ENGINE RUNNING	
PRESS [STRT], IF YOU ARE READY!		
STRT STOP	þ	

Fig. 3

Fig 3 : Selecting "ACTUATION TEST" mode.

3) Does Driver Direction Actuator work properly?



Go to "Component Inspection" procedure.



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E2354556

- 1. Check actuator.
 - 1) Ignition "OFF"

EQBF526D

- 2) Disconnect Driver Direction potentiometer.
- 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the mode actuator operates to the def mode when the connections are reversed.



5) Does the actuator work properly?

YES

Go to "Check potentiometer" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3

HA -236

HEATING, VENTILATION AND AIR CONDITIONING



Door position Voltage (3-4) Error detecting VENT 0.3 ± 0.15V BI-LEVEL(1) $1.35 \pm 0.4V$ BI-LEVEL(2) $2.25 \pm 0.4V$ Under voltage : 0.08V or less Over voltage : 4.92V or more $3.0 \pm 0.4V$ FLOOR MIX $3.6 \pm 0.4V$ DEF 4.7 ± 0.15V



Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 3. Check A/C Control Unit.
 - 1) Engine : "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "19" and "20" of A/C Control Unit while operating the mode switch.



YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ED389E33

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.